




SERVICE PARTS MANUAL



MANUAL: 28338-G01

MODEL YEAR: 1996

ISSUED: 01/02/96

SERVICE PARTS MANUAL



MODEL YEAR: 1996

CUSTOMER SERVICE DEPARTMENT PHONE 1-800-227-7029 FAX 1-800-752-6175 E-Z-GO DIVISION OF TEXTRON, INC., P.O.BOX 388, AUGUSTA, GEORGIA 30903-0388, 1-800-241-5855

LIMITED WARRANTY

TO OBTAIN A COPY OF THE LIMITED WARRANTY THAT IS APPLICABLE TO YOUR VEHICLE, CALL OR WRITE YOUR LOCAL DISTRIBUTOR, BRANCH OR E-Z-GO WARRANTY DEPARTMENT.

THE USE OF NON E-Z-GO PARTS AND HARDWARE MAY VOID YOUR WARRANTY.

TAMPERING WITH OR ADJUSTING OF GOVERNOR TO PERMIT THE VEHICLE TO OPERATE AT ABOVE FACTORY SETTINGS 12 - 15 MPH WILL VOID YOUR VEHICLE WARRANTY.

SECTIONS	Page No.
How to use the E-Z-GO Service Manual	vii
Illustrated Parts Breakdown:	
Illustration	Page No.
ACCELERATOR LINKAGE	
Accelerator Pedal Box	
Accelerator Pedal	
Accelerator Linkage	A-3
BODY AND ASSOCIATED PARTS	В
Front Cowl, Instrument Panel, Floor Panel	B-1
Seat Frame, Splash Panels	
Floormat, Seat Wrap, Side Panels, Rocker Panels	
Seat Filler Panels, Rear Fenders, Rear Panel	
BRAKE LINKAGE	C
Brake Pedal	
Brake Pedal (with lights)	
Brake Linkage	
CARBURETOR	
Carburetor	D-1
CLUTCHES	E
Drive Clutch, Belts, Driven Clutch	E-1
DIRECTION SELECTOR	F
Direction Selector	F-1
ELECTRICAL SYSTEM	G
Gauge Installation and Connections	G-1
Electrical Plate	G-2
Battery, Solenoid, Starter/Generator	G-3
ENGINE AND MUFFLER	H
Engine, Oil Filter, Spark Plugs, Muffler	H-1
ENGINE AND STARTER MOUNTING	J
Front Mount, Rear Mount, Starter/Generator	J-1
FILTERED AIR SYSTEM	K
Air Cleaner Box, Air Filter, PCV Hose	K-1

Illustrated Parts Breakdown:	
Illustration	Page No.
FRONT SUSPENSION	L
Front Axle, Spindle, Wheel Hub, Shock Absorber	
FUEL SYSTEM	M
Fuel Tank, Fuel Gauge, Fuel Filter, Fuel Pump	M-1
HORN AND LIGHTING	N
• Horn	
Headlight	N-2
Brake Pedal Wiring, Taillight	N-3
Turn Signal Assembly	N-4
REAR AXLE	0
Axle Shafts, Seals, Bearing	0-1
REAR SUSPENSION	P
Spring, Shock Absorber	P-1
SEATING	Q
Seat Bottom, Seat Back, Hip Restraint	Q-1
STARTER/GENERATOR	R
Armature, Coil, Brushes	R-1
STEERING	S
Steering Box, Steering Shaft/Column/Wheel, Tie Rods	S-1
TRUCKBED	Т
Manual Dump Bed	T-1
Bed Decals, Pivot Mounting, Bed Liner	
Tilt Latch, Bed Prop	
 Electric Dump Bed Bed Decals, Pivot Mounting, Bed Liner 	
Electric Circuit Breaker, Toggle Switch, Actuator	
Flat Bed, Bed Decals, Pivot Mounting	
Tilt Latch, Bed Prop	
Cargo Bed	T-15
WHEEL BRAKE	U
Brake Assembly, Brake Drum, Brake Shoe	U-1
WHEELS AND TIRES	V
Tire and Wheel Assembly, Wheel Rim, Valve Stem	V-1

Illustrated Parts Breakdow	n:	
Illustration		Page No.
SPECIAL TOOLS		
Special Tools Listing		Appendix - A
ACCESSORIES		
Accessory Listing		Appendix - B
ACCESSORIES		
Accessory Installation Instructions		Appendix- C
Wheel Covers		
Ramp Kit		
Electric Dump Kit		
Windshield		
Ashtray		
Hour Meter		
Rear View Mirror Kit		

Ball Hitch Kit75328Clevis Hitch Kit75329Light Bar75348Sun Top Without Bagrack75351Front Bumper Kit75355Weather Enclosure75368

Notes:
•

÷.,

HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL

This manual is divided into several sections:

- GENERAL INFORMATION
- ILLUSTRATED PARTS BREAKDOWN FOR TXT GASOLINE POWERED TRUCK
- APPENDIX

The first section, GENERAL INFORMATION, contains the following information:

- WARRANTY INFORMATION
- GENERAL INDEX
- HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL

The second section, ILLUSTRATED PARTS BREAKDOWN (IPB) FOR THE TXT GASOLINE POWERED TRUCK, contains illustrations and parts lists for all systems of your vehicle.

The third section, SERVICE ACCESSORIES AND SPECIAL TOOLS, contains a listing of E-Z-GO service accessories and special tools and that may be purchased from the company to aid in the servicing of the vehicle.

USE OF THE MANUAL

To use this manual, consult the GENERAL INDEX to locate the information or illustration required.


E-Z-GO manuals are revised periodically to coincide with vehicle changes. The manual will cover all models and model years stated on the cover page. Sections that remain unchanged have the last date they were revised in the lower inside margin. New components that are interchangeable with the previous year are automatically revised and the issue date is changed.

Introduction of some revisions varies due to supply of components; therefore, it is possible that various combinations of components may be found that are not directly reflected by each illustration. Consult the illustration that best suits your situation and then contact the Service Parts Department. It is important that the serial number of your vehicle and its model number be supplied to Service Parts when ordering any replacement components.

Locate the serial number plate (see Body and Associated Parts located in the IPB section of this manual for its location) and note the complete number shown on the plate.

All relevant systems are listed in the General Index and has an alphabetical prefix. The illustration always appears first and is followed by its related parts list. Additional illustrations and parts lists with the same prefix indicate significant changes that have taken place since the last issue.

HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL



1. WHEN THE PART NUMBER IS NOT KNOWN

- Determine the function and application of the part required. Turn to the General Index and select the most appropriate title.
- Turn to the page number indicated and locate the desired part on the illustration.
- From the illustration, obtain the item number assigned to the desired part. Refer to the accompanying description for specific information regarding the part.

2. IF YOU KNOW THE PART NUMBER

• Locate the part number or description in the appropriate column on the parts list page.

NOTE: It is suggested that you confirm that the part selected is correct by verifying it with the pictorial representation on the illustrated page.

Should an asterisk (*) appear in the part number column on the parts list page, read upwards until a part number is found. The part number is the lowest assembly sold by E-Z-GO and the asterisk (*) indicates that the part depicted is not available for sale by E-Z-GO.


NOTE: Descriptions are indented under the assembly that they are used on. That assembly is, in turn listed under the assembly that it is used on. This process is repeated until the highest final assembly is reached.

To facilitate the maintenance and repair of the vehicle, a Technician's Repair and Service Manual (P/N 28339-G01) is available from the E-Z-GO Service Parts Department.


ILLUSTRATED PARTS BREAKDOWN

,

ACCELERATOR LINKAGE




Gasoline Vehicle



ACCELERATOR LINKAGE

Gasoline Vehicle




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72062-G03	ACCELERATOR PEDAL BOX ASSEMBLY (INCLUDES ITEMS 2 - 47)	. 1
2	25853-G02	PEDAL BOX AND COVER	. 1
3	72199-G01	PIVOT BRACKET	. 1
4	25768-G01	PIVOT ROD	. 1
5	14390-G1	LOCK NUT, 3/8 - 24	. 1
6	24621-G1	NYLON WASHER, 5/16"	2
7	23860-G1	BEARING	. 2
8	72066-G01	CONTROL ARM	. 1
9	12064-G1	PUSHNUT, 1/4"	. 1
10			
11	72074-G01	CONTROL ARM LINK	. 1
12	72225-G01	SHOULDER BOLT, SOCKET BUTTON HEAD	1
13	14390-G10	LOCK NUT, #10 - 24	. 1
14			
15	25861-G01	MICRO SWITCH	. 1
16	00982-G01	SCREW, #4 - 14 X 5/8" LG	2
17			
18	72201-G01	PEDAL BOX WIRING HARNESS (WITH NUT)	1
19			
20	72072-G01	ACCELERATOR ROD	. 1
21	17677-G2	SPRING RETAINER	. 1
22	73046-G01	COMPRESSION SPRING	. 1
23	17979-G1	ACCELERATOR ROD BUSHING	. 1
24	17677-G1	SPRING RETAINER	. 1
25	01009-G01	LOCK NUT, 5/16 - 24	. 1
26	72198-G01	MICRO SWITCH CAM	. 1
27	00487-G3	SETSCREW, 1/4 - 20 X 3/8" LG	1
28	00550-G4	LOCK NUT, 5/16 - 24	. 1
29	00532-G4	LOCK NUT, 5/16 - 24	. 1
30	10385-G4	CLEVIS YOKE	. 1

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	72065-G02	ACCELERATOR CABLE (WITH NUT)	. 1
32			
33	00984-G01	SCREW, #8 - 32 X 1/2" LG.	. 4
34	00684-G6	SCREW, #8 - 10 X 1/2" LG	. 4
35			
36	25799-G01	ACCELERATOR PEDAL ASSEMBLY (INCLUDES ITEMS 37 - 40)	. 1
37	*	ACCELERATOR PEDAL	. 1
38	27844-G01	ACCELERATOR PEDAL PAD KIT (INCLUDES ITEMS 39, 40)	. 1
39	27512-G01	ACCELERATOR PEDAL PAD	. 1
40	15766-G1	OVAL RIVET, 3/8 X 15/32" LG	. 6
41	10386-G3	CLEVIS PIN, 5/16 X 1" LG	. 1
42	17838-G1	BUSHING	. 3
43	17255-G1	TEFLON WASHER, 5/16"	. 1
44	10387-G3	COTTER PIN, 3/32 x 3/4" LG	. 1
45	70134-G01	PEDAL PIVOT PIN	. 1
46	00986-G01	PUSHNUT, 19/64"	. 1
47	70116-G01	ACCELERATOR PEDAL BRACKET	. 1
48	00715-G2	BOLT, 5/16 - 18 X 3/4" LG	. 4
49			
50	72197-G01	PIVOT BRACKET	. 1
51	00414-G8	BOLT, 1/4 - 20 X 1" LG	2
52	14390-G4	LOCK NUT, 1/4 - 20	. 2
53	25760-G01	CARBURETOR LINKAGE BELLCRANK	. 1
54	14390-G1	LOCK NUT, 3/8 - 24	. 1
55			
56	25702-G01	GOVERNOR PIVOT BRACKET ASSEMBLY (INCLUDES ITEMS 57 - 59)	1
57	25655-G01	BELLCRANK BRACKET	. 1
58	25763-G01	GOVERNOR PIVOT	. 1
59	14390-G1	LOCK NUT, 3/8 - 24	. 1
60	00276-G6	BOLT, 5/16 - 24 X 3/4" LG	. 2


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	00565-G8	LOCK WASHER, 5/16"	. 2
62			
63	25737-G02	THROTTLE LINKAGE ROD (COMPLETE)	1
64	00526-G4	NUT, #10 - 32	AR
65	24465-G1	BALL JOINT SOCKET	AR
66	25737-G03	GOVERNOR LINKAGE ROD	1
67	25737-G01	CARBURETOR LINKAGE ROD	. 1
68			
69	25690-G01	GOVERNOR BELLCRANK ASSEMBLY (INCLUDES ITEMS 70 - 74)	. 1
70	25765-G01	GOVERNOR BELLCRANK	. 1
71	24479-G1	BALL JOINT BALL	. 1
72	00734-G5	LOCK NUT, #10 - 32	. 1
73	22751-G2	GOVERNOR BRACKET	. 1
74	14390-G4	LOCK NUT, 1/4 - 20	. 1
75	00491-G4	SETSCREW, 1/4 - 20 X 1/2" LG	. 1
76	25738-G01	GOVERNOR TO ACCELERATOR BRACKET SPRING	1
77			
78	25653-G01	ACCELERATOR CABLE BRACKET	1
79	*	WASHER (PROVIDED ON DIFFERENTIAL)	2
80	*	NUT (PROVIDED ON DIFFERENTIAL)	2
81	12064-G3	PUSHNUT, 3/16"	1
82			
83	72154-G01	CHOKE CABLE ADAPTER	. 1
84	72155-G02	ADAPTER RETAINER	1
85	72401-G02	CHOKE CONTROL ASSEMBLY (COMPLETE WITH NUTS)	1
86	00568-G4	LOCK WASHER, 9/16"	. 1
87	00545-G4	NUT, 9/16 - 18	. 1
88			
89	26728-G01	CHOKE BRACKET	1
90	00544-G4	NUT, 5/16 - 24	. 2

BODY AND ASSOCIATED PARTS


Gasoline Vehicle



Gasoline Vehicle




BODY AND ASSOCIATED PARTS



Gasoline Vehicle

BODY AND ASSOCIATED PARTS



BODY AND ASSOCIATED PARTS

When ordering parts, please specify the model and serial number of the product. * Indicates a component that is not available as an individual part. G** Indicates consult Customer Service Department for additional information.

2 3 4 5 ITEM PART NO. 1 DESCRIPTION QTY. 70047-G01 UPPER FLOORPAN 1 1 2 14601-G11 RIVET, 3/16 X 9/16" LG..... 9 3 70132-G01 4 LOWER FLOORPAN 1 14601-G11 RIVET, 3/16 X 9/16" LG..... 5 7 SWITCH ACCESS COVER..... 6 70164-G01 1 7 27166-G02 FRONT SHIELD 8 1 FRONT SHIELD BRACE 9 71015-G01 2 BOLT. 1/4 - 14 X 3/4" LG..... 00114-G6 4 10 WASHER, 1/4" 16469-G7 11 2 RATCHET FASTENER 16816-G2 12 2 13 71143-G01 SPLASH PANEL 14 1 FOAM TAPE, 3/4 X 2" LG. 15 27919-G02 3 16 71102-G01 BOLT, 1/4 - 20 X 3/4" LG. 1 17 18 71151-G01 INSTRUMENT PANEL ASSEMBLY (INCLUDES ITEMS 19 - 22)..... 1 71153-G01 PASSENGER SIDE DEFLECTOR 19 1 DRIVER SIDE DEFLECTOR 71154-G01 20 1 SCREW. #8 - 18 X 5/8" LG..... 00614-G5 21 6 71158-G01 4 CUP INSERT 22 1 23 71177-G01 SAFETY LABEL 24 1 25 SERIAL NUMBER PLATE 26 1 CAPACITY PLATE 27 1 10570-G9 RIVET. 1/8 X 11/32" LG..... 28 4 29 SCREW, #10 - 32 X 1/2" LG. 30 00740-G4 4


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	00921-G8	NUT, #10 - 32	4
32	71115-G01	VINYL TRIM (PASSENGER SIDE)	1
33	71115-G02	VINYL TRIM (DRIVER SIDE)	1
34	14601-G13	RIVET, 5/32 X 9/16" LG	10
35	71051-G**	COWL	. 1
36	19817-G2	E-Z-GO NAMEPLATE (GOLD)	. 1
37	12064-G3	PUSHNUT, 3/16"	. 2
38			
39	14601-G13	RIVET, 5/32 X 9/16" LG	. 2
40	71055-G01	RIVET, 3/16 X 3/8" LG	. 7
41			
42	71056-G01	BOLT, 5/16 - 18 X 5/8" LG	. 4
43	00570-G2	WASHER, 5/16"	. 4
44			
45	70244-G02	SPLASH PANEL	1
46	00715-G2	BOLT, 5/16 - 18 X 13/16" LG	. 2
47	00438-G8	BOLT, 5/16 - 18 X 1" LG	. 2
48	00559-G8	WASHER, 5/16"	. 2
49	11098-G6	LOCK NUT, 5/16 - 18	. 2
50			
51	70245-G01	BATTERY TRAY	1
52	00715-G2	BOLT, 5/16 - 18 X 13/16" LG	. 2
53	00438-G8	BOLT, 5/16 - 18 X 1" LG	2
54	00571-G2	WASHER, 5/16"	2
55	11098-G6	LOCK NUT, 5/16 - 18	2
56			
57	70384-G01	SEAT FRAME	1
58	70200-G01	SCREW, 3/8 - 16 X 1/4" LG	. 2
59	70113-G01	RUBBER BUMPER	. 2
60	11027-G1	LOCK NUT, 5/16 - 18	. 4

BODY AND ASSOCIATED PARTS

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61			
62	71379-G**	SEAT WRAP PANEL	. 1
63	10570-G10	RIVET, 5/32 X 9/16" LG	. 8
64	71609-G01	HINGE PLATE	. 2
65	10570-G11	RIVET, 3/16 X 11/16" LG	4
66			
67	71674-G**	DRIVER SIDE SIDE PANEL	. 1
68	71674-G**	PASSENGER SIDE SIDE PANEL	1
69	10570-G10	RIVET, 5/32 X 9/16" LG	. 4
70	10570-G12	RIVET, 1/4 X 9/16" LG	. 4
71	16469-G7	FENDER WASHER	. 4
72	71196-G01	DECAL ("WORKHORSE")	. 2
73			
74	70135-G01	PEDAL PIVOT COVER	. 1
75	70048-G06	FLOORMAT	1
76			
77	71190-G01	DRIVER SIDE ROCKER PANEL	. 1
78	71190-G02	PASSENGER SIDE ROCKER PANEL	. 1
79	71191-G01	DRIVER SIDE BRACE	. 1
80	71191-G02	PASSENGER SIDE BRACE	. 1
81	16705-G9	CARRIAGE BOLT, 1/4 - 20 X 1 1/4" LG	. 4
82	19247-G2	SPACER (13/32" THICK)	. 2
83	19247-G3	SPACER (9/32" THICK)	. 2
84	00559-G7	WASHER, 1/4"	. 8
85	14390-G4	LOCK NUT, 1/4 - 20	. 8
86	16705-G1	CARRIAGE BOLT, 1/4 - 20 X 1" LG	. 4
87	23726-G2	SPACER (1/4" THICK)	. 4
88	71764-G01	SILL PLATE TREAD	. 1
89			
90	71588-G01	DRIVER SIDE SEAT FILLER PANEL	. 1


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
91	71588-G02	PASSENGER SIDE SEAT FILLER PANEL	1
92	10570-G10	RIVET, 5/32 X 9/16" LG	6
93	20271-G7	HOLE PLUG (VEHICLES WITHOUT TOP)	2
94			
95	71586-G01	DRIVER SIDE FENDER	1
96	71586-G02	PASSENGER SIDE FENDER	1
97	71586-G03	DRIVER SIDE FENDER (WITH TAILLIGHT)	1
98	71586-G04	PASSENGER SIDE FENDER (WITH TAILLIGHT)	1
99	00414-G7	BOLT, 1/4 - 20 X 7/8" LG	12
100	00559-G7	WASHER, 1/4"	24
101	14390-G4	LOCK NUT, 1/4 - 20	12
102			
103	71587-G01	REAR PANEL	1
104	71055-G01	RIVET, 3/16 X 3/8" LG	4

BRAKE LINKAGE




Gasoline Vehicle

BRAKE LINKAGE



BRAKE LINKAGE

Gasoline Vehicle




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70264-G01	BRAKE PEDAL ASSEMBLY (INCLUDES ITEMS 2 - 9)	
2	*	VEHICLES WITHOUT BRAKE LIGHTS	
3	70257-G01	BRAKE PEDAL PAD	
4	70254-G01		
5	70256-G01		
6	16409-G1	RIVET, 3/8 X 15/32" LG.	
7	15932-G2		
8	11737-G1	PARK BRAKE TORSION SPRING	
9	12064-G1	PUSH NUT, 5/16	1
10 11	70263-G01	BRAKE PEDAL ASSEMBLY (INCLUDES ITEMS 12 - 32) VEHICLES WITH BRAKE LIGHTS	1
12	70264-G01	BRAKE PEDAL ASSEMBLY (INCLUDES ITEMS 2 - 9)	
13			
14	70258-G02	BRAKE PEDAL PLATE	1
15	00737-G8	SCREW, #10 - 24 X 1" LG	. 4
16	00739-G1	RUBBER NUT, #10 - 24	. 2
17	22362-G3	BRAKE PEDAL STANDOFF	. 2
18	27137-G01	CONICAL SPRING	. 2
19	11098-G7	LOCK NUT, #10 - 24	. 2
20		· · · ·	
21	10606-G8	MICRO SWITCH	. 1
22	00645-G2	SCREW, #6 - 32 X 1 1/4" LG	
23	00559-G5	WASHER, #10	
24	00559-G3	WASHER, #6	
25	00565-G3	LOCK WASHER, #6	
26	00525-G5	NUT, #6 - 32	
27			
28	*	BRASS SCREW	2
29	00567-G3	LOCK WASHER, #6	

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	14628-G1	FASTON TAB, 5/16 X 5/16" LG	. 2
31	24605-G1	WIRE	. 1
32	17618-G1	NYLON CLAMP	. 3
33			
34	70096-G01	SHOULDER BOLT, 3/8 - 16 X 3" LG	. 1
35	11079-G1	FLANGED BUSHING	2
36	70138-G01	TORSION SPRING	. 1
37	00643-G1	WASHER, 3/8	. 1
38	11098-G5	NUT, 3/8 - 16	. 1
39			
40	70080-G01	PARK BRAKE CATCH BRACKET	1
41	00414-G6	BOLT, 1/4 - 20 X 3/4" LG	. 2
42	11027-G2	LOCK NUT, 1/4 - 20	. 2
43			
44	70113-G01	ADJUSTABLE BUMPER	. 1
45	11027-G1	LOCK NUT, 5/16 - 18	. 1
46			
47	70098-G01	KICK OFF CAM PIVOT	. 1
48	10097-G6	FLANGED BEARING	. 2
49	25103-G1	KICK-OFF CAM	1
50	00491-G4	SETSCREW, 1/4 - 20 X 1/2" LG	. 2
51	14134-G4	SPACER	. 1
52			
53	70097-G01	PARK BRAKE KICK-OFF LINK	. 1
54	17838-G1	BEARING	. 2
55	20835-G1	TEFLON WASHER	2
56	00559-G8	WASHER, 5/16	. 2
57	10387-G3	COTTER PIN, 3/32 X 3/4" LG	. 2
58			
59	70272-G04	COMPENSATOR ASSEMBLY (INCLUDES ITEMS 60 - 69)	. 1

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
60	*	BRAKE YOKE	. 1
61	25882-G04	LINK ROD	. 1
62	15121-G1	WASHER, 3/8"	. 2
63	17979-G1	ACCELERATOR ROD BUSHING	. 1
64	23061-G2	TUBE	. 1
65	23463-G1	COMPRESSION SPRING	. 1
66	00532-G4	NUT, 5/16 - 24	. 2
67	28082-G01	EQUALIZER BRACKET	. 1
68	00963-G01	SPHERICAL NUT, 5/16 - 24	. 1
69	11098-G9	LOCK NUT, 5/16 - 24	. 1
70			
71	10386-G3	CLEVIS PIN, 5/16 X 15/16" LG	. 1
72	10387-G3	COTTER PIN, 3/32 X 3/4" LG	. 1
73			
74	70453-G01	BRAKE CABLE (DRIVER SIDE)	. 1
75	70349-G02	BRAKE CABLE (PASSENGER SIDE)	. 1
76	28083-G01	BRAKE COMPENSATOR BUMPER	. 2
77	12305-G1	RETAINING RING	. 4
78			
79	10386-G3	CLEVIS PIN, 5/16 X 15/16" LG	. 2
80	10387-G3	COTTER PIN, 3/32 X 3/4" LG	. 2
81	12416-G1	NYLON CLAMP	. 2


CARBURETOR




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26645-G04	CARBURETOR ASSEMBLY (INCLUDES ITEMS 2 - 17)	1
2	26835-G01	PILOT SCREW	1
3	26847-G01	PILOT SCREW NUT	1
4	26649-G03	PILOT JET (#50)	1
5	26841-G01	PLUG	1
6	26731-G01	BOWL SCREEN GASKET	1
7	26647-G01	NEEDLE VALVE	1
8	26837-G01	MAIN NOZZLE	1
9	26646-G05	MAIN JET (#94)	1
10	26648-G01	FLOAT	1
11	26840-G01	FLOAT PIN	1
12	26843-G01	FLOAT BOWL GASKET	1
13	26844-G01	FLOAT CHAMBER	1
14	26839-G01	BOWL SCREW	1
15	26730-G01	BOWL GASKET	1
16	26846-G01	DRAIN SCREW	1
17	26845-G01	SPRING	1
18			
19	26650-G01	VENT TUBE	2
20			
21	26725-G01	CARBURETOR MOUNT GASKET	1
22	26637-G01	CARBURETOR INSULATOR	1
23	26726-G01	CARBURETOR MOUNT GASKET	1

CLUTCHES

Gasoline Vehicle




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26952-G01	DRIVE CLUTCH	. 1
2	25757-G1	PILOT WASHER	. 1
3			
4			
5	00566-G2	LOCK WASHER, 7/16"	
6	00473-G9	BOLT, 7/16 - 20 X 6 1/2" LG	
7	26414-G01	STARTER / GENERATOR BELT	. 1
8			
9	26301-G02	DRIVEN CLUTCH ASSEMBLY (INCLUDES ITEMS 10 - 19)	
10	27270-G01	HEAVY DUTY RETAINING RING	
11	26304-G01	COMPRESSION SPRING	1
12			
13	00979-G01	SCREW, #10 - 24	. 3
14	26479-G01	RAMP BUTTON	. 3
15			
16	24600-G1	SPACER WASHER	. 1
17	*	CAM	. 1
18	*	MOVABLE SHEAVE	1
19	*	SHEAVE AND POST	1
20	25756-G1	RETAINING WASHER	1
21	00565-G8	LOCK WASHER, 5/16"	. 1
22	00441-G8	BOLT, 5/16 - 18 X 4" LG	1
23	72054-G01	DRIVE BELT	. 1



ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	25700-G06	DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 36)	. 1
2	25684-G01	DIRECTION SELECTOR BRACKET	1
3	00414-G6	SCREW, 1/4 - 20 X 3/4" LG	2
4	00559-G7	WASHER, 1/4"	2
5	11027-G2	LOCK NUT, 1/4 - 20	2
6			
7	25664-G1	BUSHING	. 1
8	27537-G01	DIRECTION SELECTOR SHAFT	. 1
9	25745-G01	DIRECTION SELECTOR CAM	. 1
10	14390-G1	LOCK NUT, 3/8 - 24	. 1
11			
12	10606-G1	MICRO SWITCH	. 1
13	27151-G01	MICRO SWITCH SPACER	. 1
14	00645-G2	SCREW, #6 - 32 X 1 1/4" LG	. 2
15	00559-G3	WASHER, #6	. 2
16	00565-G3	LOCK WASHER, #6	. 2
17	00525-G5	NUT, #6 - 32	. 2
18			
19	14628-G1	FASTON TAB	. 1
20	*	SCREW AND WASHER ASSEMBLY	. 2
21	00567-G3	LOCK WASHER, #6	. 2
22			
23	17940-G5	REVERSE WARNING	1
24	00138-G5	SCREW, #6 - 32 X 5/8" LG	2
25	00559-G3	WASHER, #6	2
26	00565-G3	LOCK WASHER, #6	. 2
27	00525-G5	NUT, #6 - 32	. 2
28			
29	72341-G01	SHIFTER CONTROL CABLE	. 2
30	23176-G1	CLEVIS PIN, 5/16 X 1/2" LG	2


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	10387-G8	COTTER PIN, 1/16 X 3/4" LG	. 2
32	25946-G01	PIVOT ARM	. 1
33	27764-G01	SPRING	. 2
34	23726-G5	SPACER	. 2
35	25727-G01	CUP WASHER	. 4
36	11098-G7	NUT, #10 - 24	2
37			
38	26830-G01	SHIFTER LEVER NUT, M8 X 1.25 MM	. 1
39			
40	71905-G01	DIRECTION SELECTOR HANDLE	. 1
41	00740-G4	SCREW, #10 - 32 X 1/2" LG	. 1


ELECTRICAL SYSTEM



Gasoline Vehicle

ELECTRICAL SYSTEM






ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	73030-G01	CONSOLE PLATE (IGNITION SWITCH ONLY)	. 1
2	71181-G01	CONSOLE PLATE DECAL (IGNITION SWITCH ONLY)	. 1
3			1
4	73030-G03	CONSOLE PLATE (SWITCH WITH WARNING LIGHTS)	. 1
5	71183-G01	CONSOLE PLATE DECAL (SWITCH WITH WARNING LIGHTS)	. 1
6			
7	73030-G04	CONSOLE PLATE (SWITCH, OIL WARNING LIGHT AND FUEL GAUGE)	. 1
8	71127-G01	CONSOLE PLATE DECAL (SWITCH, LIGHT AND GAUGE)	. 1
9			
10	33623-G02	DRIVE RIVET	. 2
11	33639-G0*	IGNITION SWITCH (VEHICLES WITH LIGHTS)	. 1
12	00568-G6	LOCK WASHER, 3/4"	. 1
13	17137-G1	FACE NUT	. 1
14	17063-G1	IGNITION KEY	. AR
15	27778-G01	IGNITION SWITCH HARNESS	. 1
16			
17	23474-G1	INDICATOR LIGHT	. A/R
18	74030-G01	INDICATOR LIGHTS WIRE HARNESS	. 1
19			
20	21553-G1	FUEL GAUGE	
21	74029-G01	FUEL GAUGE/INDICATOR LIGHT WIRE HARNESS	. 1
22			
23	25978-G74	WIRE, RED	. 1
24	25978-G122	WIRE, RED	. 1
25			
26			
27	27740-G03	ELECTRICAL PLATE ASSEMBLY (INCLUDES ITEMS 28 - 42)	
28	27738-G01		
29	27739-G01		
30	27746-G01	IGNITOR ASSEMBLY	. 1

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	27153-G01	SOLENOID	. 1
32	00650-G7	WASHER, 1/4"	. 6
33	00565-G7	LOCK WASHER, 1/4"	. 6
34	00532-G1	NUT, 1/4 - 20	. 5
35	12914-G1	FASTON TAB, 5/16" x 5/16"	. 2
36	25978-G56	WIRE, BLACK, 5 3/4" LG	. 1
37	12914-G2	FASTON TAB, 3/8" x 13/32"	2
38	00526-G4	NUT, #10 - 32	. 2
39	00565-G8	LOCK WASHER, 5/16"	2
40	00544-G4	NUT, 5/16 - 24	2
41	00565-G5	LOCK WASHER, #10	2
42	72003-G01	COVER SPACER	. 1
43			
44	11027-G2	LOCK NUT, 1/4 - 20	. 3
45	72004-G01	ELECTRICAL PLATE COVER	. 1
46			
47	72344-G01	CONTROL HARNESS	. 1
48			
49	25976-G11	WIRE, BLACK	. 1
50	25972-G58	WIRE (SOL - F2)	. 1
51			
52	26651-G02	IGNITION PICKUP ASSEMBLY (INCLUDES ITEM 53)	. 1
53	26707-G01	BOLT AND WASHER ASSEMBLY, M5 X .8 X 10 MM LG	. 1
54			
55	26652-G01	IGNITION COIL ASSEMBLY (INCLUDES ITEMS 56 - 61)	. 1
56	*	IGNITION COIL	. 1
57	*	SPACER	. 1
58	*	LOCK WASHER	. 1
59	*	NUT	. 1
60	*	SCREW	. 1


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	13632-G1	NUT, M6 X 1" LG	. 2
62			
63	XXXXX-XX	STARTER / GENERATOR (SEE SECTION R)	x
64	25887-G01	WIRE (F1 - A2)	. 1
65	25682-G1	TERMINAL COVER	. 3
66			
67	20294-G3	GROUND CABLE	1
68	00715-G3	BOLT, 5/16 - 18 X 1 1/4" LG	1
69	11027-G1	LOCK NUT, 5/16-18	1
70	26676-G01	SCREW, M6 X 1 X 23 MM LG	1
71			
72	XXXXX-G**	BATTERY, 12 VOLT	1
73	00952-G6	BOLT, 5/16 - 18 X 3/4" LG	1
74	00565-G8	LOCK WASHER, 5/16"	1
75	00571-G2	WASHER, 5/16"	1
76	72101-G01	BATTERY HOLD DOWN	1
77	*	BOLT, 5/16 - 18 X 1 1/4" LG	2
78	*	LOCK WASHER, 5/16"	2
79	*	NUT, 5/16 - 18	2
80			
81	25972-G12	WIRE (B- GRD)	1
82	25972-G33	WIRE (B+ - SOL)	1
83			
84	17618-G1	NYLON CLAMP	. 5



2 3 26 4 26 5 26 6 25 7 25 8 26 9	2500-G01 6631-G01 6727-G01 6667-G01 5523-G3 5523-G2 6733-G01 6657-G01	ENGINE, 350CC TIMING BELT COVER GROMMET CARBURETOR / AIR BOX GASKET STUD SPARK PLUG, RESISTOR SPARK PLUG, NGK BP4ES SPARK PLUG WIRE SET (2, WITH BOOTS) IGNITION COIL BRACKET	1 2 AR 2 1
3 26 4 26 5 26 6 25 7 25 8 26 9 10	6727-G01 6667-G01 5523-G3 5523-G2 6733-G01	CARBURETOR / AIR BOX GASKET STUD SPARK PLUG, RESISTOR SPARK PLUG, NGK BP4ES SPARK PLUG WIRE SET (2, WITH BOOTS)	1 2 AR 2 1
4 26 5 26 6 25 7 25 8 26 9 10 26	6727-G01 6667-G01 5523-G3 5523-G2 6733-G01	CARBURETOR / AIR BOX GASKET STUD SPARK PLUG, RESISTOR SPARK PLUG, NGK BP4ES SPARK PLUG WIRE SET (2, WITH BOOTS)	1 2 AR 2 1
5 26 6 25 7 25 8 26 9 10 26	6667-G01 5523-G3 5523-G2 6733-G01	STUD SPARK PLUG, RESISTOR SPARK PLUG, NGK BP4ES SPARK PLUG WIRE SET (2, WITH BOOTS)	2 AR 2 1
6 25 7 25 8 26 9 10 26	5523-G3 5523-G2 6733-G01	SPARK PLUG, RESISTOR SPARK PLUG, NGK BP4ES SPARK PLUG WIRE SET (2, WITH BOOTS)	AR 2 1
7 25 8 26 9 10 26	5523-G2 6733-G01	SPARK PLUG, NGK BP4ES SPARK PLUG WIRE SET (2, WITH BOOTS)	2 1
8 26 9 10 26	6733-G01	SPARK PLUG WIRE SET (2, WITH BOOTS)	1
9 10 26			
10 26	6657-G01	IGNITION COIL BRACKET	1
	6657-G01	IGNITION COIL BRACKET	1
11			
12 X	xxxx-xx	CARBURETOR (SEE SECTION D)	x
13			
14 26	6600-G01	VALVE COVER	1
15 26	6719-G01	VALVE COVER GASKET	1
16 26	6676-G01	BOLT, M6 X 1 X 23 MM LG	6
17			
18 26	6601-G01	OIL FILLER CAP	1
19 26	6720-G01	"O" RING	1
20			
21 72	2019-G01	MUFFLER	1
22 25	5532-G1	BOLT AND WASHER, M8 X 1.25 X 18 MM LG.	2
23 2	5531-G1	EXHAUST GASKET	1
24			
25 00	0438-G8	BOLT, 5/16 - 18 X 1" LG	1
26 00	0565-G8	LOCK WASHER, 5/16"	1
27 00	0642-G8	WASHER, 5/16"	
28			
	0276-G6	SCREW, 5/16 - 24 X 3/4" LG.	2
	0565-G8	LOCK WASHER, 5/16"	2

ITEM	PART NO.	1 2 3		ment for additional information.	OTV
	PART NU.	1 2 3	4 5	DESCRIPTION	QTY.
31					
32	26630-G01			VER	
33	26626-G01				
34	26678-G01	BOLT, M6	X 1 X 1	2 MM LG	. 3
35					
36	26591-G01	OIL FILTE	R		. 1
37	26710-G01			ING	
38	26680-G01	BOLT AND	WASH	ER, M6 X 1 X 12 MM LG	. 3
		i			

ENGINE AND STARTER MOUNTING




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72010-G01	FRONT ENGINE MOUNT	. 1
2	00463-G4	BOLT, 7/16 - 14 X 1 1/2" LG	. 2
3	00566-G2	LOCK WASHER, 7/16"	2
4	00922-G3	WASHER, 7/16"	. 2
5	15121-G1	WASHER, 1 1/4" X 3/8"	. 1
6	72044-G01	MOUNT BRACKET	. 1
7	00428-G6	BOLT, 3/8 - 16 X 2 3/4" LG	. 2
8	11098-G5	LOCK NUT, 3/8 - 16	2
9	00643-G1	WASHER, 3/8"	. 2
10	00430-G4	BOLT, 3/8 - 16 X 4 1/2" LG	. 1
11	72051-G02	WASHER, 2 1/2 X 11/32 X 1/8"	. 1
12	72050-G01	PLASTIC WASHER	. 4
13	72051-G01	WASHER, 2 1/2 X 5/8 X 1/8"	. 2
14	72015-G01	ISOLATION MOUNT	. 1
15	11098-G5	LOCK NUT, 3/8 - 16	. 1
16			
17	XXXXX-XX	DIFFERENTIAL (SEE REAR AXLE SECTION 0)	x
18			
19	72011-G01	REAR ENGINE MOUNT	. 1
20	72035-G01	"U" BOLT	. 2
21	00922-G3	WASHER, 7/16"	. 4
22	00734-G1	LOCK NUT, 7/16 - 14	. 4
23			
24	00463-G4	BOLT, 7/16 - 14 X 1 1/2" LG	. 2
25	00566-G2	LOCK WASHER, 7/16"	2
26	00922-G3	WASHER, 7/16"	. 2
27			
28	27432-G02	ENGINE GUARD	1
29	00463-G4	BOLT, 7/16 - 14 X 1 1/2" LG	. 4
30	00566-G2	LOCK WASHER, 7/16"	. 4


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QT
31	00922-G3	WASHER, 7/16"	4
32			
33	XXXXX-XX	STARTER / GENERATOR (SEE SECTION R)	1
34	00938-G4	BOLT, 1/2 - 13 X 8" LG	1
35	00560-G3	WASHER, 1/2"	2
36	00566-G3	LOCK WASHER, 1/2"	1
37	00533-G1	NUT, 1/2 - 13	1
38			
39	72045-G01	STARTER / GENERATOR ADJUSTER	1
40	00544-G5	JAM NUT, 3/8 - 16	1
41	00532-G5	NUT, 3/8 - 16	1
42	00560-G1	WASHER, 3/8"	1
43	12064-G1	PUSH NUT, 5/16"	1
44			
45	72017-G01	TRANSAXLE BRACKET	1
46	75048-G01	SPACER	1
47	26826-G01	LOCK WASHER, M8	2
48	26827-G01	NUT, M8 X 1.25 MM	2
49	00439-G2	BOLT, 5/16 - 18 X 1 1/4" LG	1
50	11098-G6	LOCK NUT, 5/16 - 18	1

ENGINE AND STARTER MOUNTING

FILTERED AIR SYSTEM



ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72142-G01	AIR FILTER HOUSING	. 1
2	72146-G01	INLET COVER	. 1
3	00614-G5	SCREW, #8 - 18 X 5/8" LG	6
4			
5	72147-G01	HOUSING MOUNT GROMMET	. 2
6	23726-G7	HOUSING MOUNT SPACER	. 2
7	26671-G01	BOLT WITH WASHER, M6 X 1 X 30 MM LG	. 2
8	26701-G01	WASHER, 6.5 X 20 X 1.6 MM	2
9			
10	23726-G6	CARBURETOR MOUNT SPACER	. 4
11	72514-G01	STUD	. 2
12	13632-G1	NUT, M6 X 1 MM	. 2
13	51400-G1	LOCK WASHER, 6 MM	2
14			
15	72151-G01	PCV HOSE	. 1
16			
17	72143-G01	AIR FILTER COVER	1
18	72148-G01	AIR FILTER LATCH	. 3
19			
20	72144-G01	AIR FILTER ELEMENT	. 1
21			
22	74093-G01	WARNING LABEL	. 1




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70001-G01	FRONT AXLE	. 1
2			
3	70220-G01	DRIVER SIDE SPINDLE ASSEMBLY (INCLUDES ITEMS 4 - 12)	. 1
4	*	DRIVER SIDE SPINDLE	. 1
5	16623-G1	BEARING	. 2
6	18456-G1	GREASE FITTING	. 1
7	25146-G1	GREASE SEAL	. 1
8	19932-G1	WHEEL HUB ASSEMBLY (INCLUDES ITEMS 17, 18)	. 1
9	19862-G1	WHEEL BOLT, 1/2 - 20	. 4
10	50892-G1	BEARING AND RACE ASSEMBLY (COMPLETE)	2
11	12093-G1	SLOTTED NUT, 17/32	. 1
12	00798-G8	COTTER PIN, 5/32 X 1 3/4" LG	. 1
13			
14	70221-G01	PASSENGER SIDE SPINDLE ASSEMBLY (INCLUDES ITEMS 5 - 12, 15)	. 1
15	*	PASSENGER SIDE SPINDLE	1
16			
17	12091-G1	SPINDLE CAP	2
18			
19	70327-G0 1	SPINDLE PIN, 1/2 - 13 X 5 1/2" LG.	. 2
20	00571-G5	WASHER, 1/2"	. 4
21	70328-G01	SPINDLE PIN TUBE	2
22	16982-G1	THRUST WASHER	2
23	14390-G6	LOCK NUT, 1/2 -13	. 2
24	10387-G2	COTTER PIN, 3/32 X 1" LG	. 2
25			
26	70324-G01	SHOCK ABSORBER	. 2
27	10435-G1	SHOCK ABSORBER WASHER	. 8
28	10194-G1	RUBBER SHOCK ABSORBER BUSHING	. 8
29	00532-G6	NUT, 3/8 - 24	. 4
30			

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	70422-G01	LEAF SPRING (HEAVY DUTY)	. 2
32	70163-G02	SPRING PLATE	. 4
33	00463-G4	BOLT, 7/16 - 14 X 1 1/2" LG	6
34	00734-G1	LOCK NUT, 7/16 - 14	. 12
35	00463-G6	BOLT, 7/16 - 14 X 1 3/4" LG	. 6




FUEL SYSTEM




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72092-G01	FUEL TANK (WITHOUT REMOTE SENDING UNIT)	. 1
2	14099-G2	FUEL TANK CAP (WITH GAUGE)	1
3			
4	00438-G8	BOLT, 5/16 - 18 X 1" LG	2
5	00559-G8	WASHER, 5/16"	4
6	15121-G1	WASHER, 1 1/4" X 3/8"	. 1
7	72234-G01	PLASTIC SPACER	. 1
8	11098-G6	LOCK NUT, 5/16 - 18	2
9	17470-G1	FUEL SYSTEM TUBE, 2 5/8" LG. (BULK)	. 1
10	18292-G1	TUBING CLAMP	5
11	72084-G01	FUEL FILTER	. 1
12	17470-G1	FUEL SYSTEM TUBE, 4" LG. (BULK)	1
13	72021-G01	FUEL PUMP	. 1
14	17470-G1	FUEL SYSTEM TUBE, 16" LG. (BULK)	AR
15	11391-G4	HOSE CLAMP	3
16	27183-G01	PULSE TUBE, 16" LG. (SOLD IN 12" INCREMENTS)	AR
17			
18	72244-G01	FUEL PUMP MOUNT	1
19	00715-G2	SELF THREADING SCREW, 5/16 - 18 X 13/16" LG	2
20	11027-G2	LOCK NUT, 1/4 - 20	2
21			
22	22280-G1	VINYL TRIM, 14" LG. (BULK)	1
23	17618-G1	NYLON CLAMP	1
24			
25	*	FUEL TANK ASSEMBLY (INCLUDES ITEMS 26 - 28)	. 1
26	72092-G02	FUEL TANK	1
27	20039-G1	САР	. 1
28	20048-G2	FUEL SENDER (ELECTRIC FUEL GAUGE)	. 1
29	*	FUEL TANK ASSEMBLY (INCLUDES ITEMS 26, 27, 30)	. 1
30	20048-G4	FUEL SENDER (LOW FUEL LIGHT)	1

HORN AND LIGHTING




Gasoline Vehicle

HORN AND LIGHTING




HORN AND LIGHTING

Gasoline Vehicle




Service Parts Manual



iTEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	73204-G01	FUSE BLOCK AND BRACKET	. 1
2	71010-G01	RIVET, 5/32 X 3/8" LG	. 2
3	00106-G6	SELF THREADING SCREW, #12 - 24 X 3/4" LG	. 1
4	18392-G1	15 AMP FUSE	. 3
5			
6	17318-G1	HORN SWITCH	. 1
7	17318-G2	HORN SWITCH CAP AND NUT	1
8	19233-G1	HORN SWITCH PLATE	1
9	14601-G7	STAINLESS STEEL RIVET, 9/16"	2
10	27068-G01	HORN SWITCH BOOT	1
11	32860-G1	HORN	. 1
12	00414-G5	BOLT, 1/4 - 20 X 5/8" LG.	. 1
13	00559-G8	WASHER, 5/16"	. 1
14	00891-G2	LOCK NUT, 1/4 - 20	1
15	73214-G01	HORN HARNESS	. 1
16	25974-G22	WIRE	. 1
17	25977-G40	WIRE	. 1
18	17618-G1	NYLON CLAMP	. 5
19			
20	74002-G01	PASSENGER SIDE LIGHT BAR BRACKET	. 1
21	74002-G02	DRIVER SIDE LIGHT BAR BRACKET	1
22	74001-G01	LIGHT BAR	1
23	00114-G6	SCREW, 1/4 - 14 X 3/4" LG	. 8
24	00414-G6	BOLT, 1/4 - 20 X 3/4" LG.	2
25	11027-G2	LOCK NUT, 1/4 - 20	. 2
26			
27	74004-G01	REPLACEMENT HEADLIGHT BULB	AR
28	74005-G01	REPLACEMENT MARKER LIGHT BULB	AR
29	74006-G01	REPLACEMENT TURN LIGHT BULB	AR
30			

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	32739-G2	TAIL LIGHT	2
32			
33	74042-G01	LIGHT HARNESS	. 1
34			
35	17867-G1	TURN SIGNAL (WITH MOUNTING HARDWARE)	1
36	21640-G1	TURN SIGNAL FLASHER	. 1
37	20965-G3	STEERING COLUMN COVER	. 1
		·	

REAR AXLE



ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72031-G01	REAR AXLE (STANDARD) (W/O BRAKES) (INCLUDES ITEMS 4 - 35)	. 1
2	72031-G02	REAR AXLE (HP) (W/O BRAKES) (INCLUDES ITEMS 4 - 35)	. 1
3			
4	26766-G01	AXLE SHAFT SEAL	. 1
5	26828-G01	WASHER, 10 MM	. 10
6	26829-G01	NUT, 10 MM X 1.5 MM	. 10
7	26667-G01	STUD, M10 X 1.5 X 40 MM LG	. 5
8	26761-G01	INPUT SHAFT SEAL	1
9	26815-G01	SHIFTER CABLE BRACKET	. 1
10	26823-G01	BOLT, M8 X 1.25 X 100 MM LG.	. 8
11	26762-G01	SHIFTER SHAFT SEAL	1
12			
13	72017-G01	TRANSAXLE BRACKET	1
14	26826-G01	LOCK WASHER, M8	4
15	26827-G01	NUT, M8 X 1.25 MM	4
16			
17			
18			
19	75048-G01	SPACER	. 1
20	26814-G01	RETAINING RING	. 4
21	26811-G01	BALL BEARING	2
22	72056-G01	PASSENGER SIDE AXLE SHAFT	. 1
23	72057-G01	DRIVER SIDE AXLE SHAFT	1
24			
25	72115-G01	DRIVER SIDE AXLE TUBE	. 1
26	72116-G01	PASSENGER SIDE AXLE TUBE	. 1
27	26824-G01	BOLT, M8 X 1.25 X 110 MM LG	. 1
28	72053-G01	BOLT, M8 X 1.25 X 120 MM LG.	. 1
29			
30	26770-G01	OIL DRAIN PLUG	. 1

REAR AXLE

When ordering parts, please specify the model and serial number of the product. * Indicates a component that is not available as an individual part.


G** Indicates	consult Cu	istomer Ser	vice Depart	iment for	additional	information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	26771-G01	GASKET, 14 MM	1
32	26768-G01	OIL CHECK PLUG	
33	26769-G01	GASKET, 8 MM	1
34			
35	26772-G01	OIL FILLER PLUG	1

Gasoline Vehicle


REAR AXLE

.



ITEM	PART NO.	12345DESCRIPTION	QTY.
1	74135-G01	LEAF SPRING	. 2
2	72028-G01	ISOMOUNT BASE PLATE	2
3	72117-G01	ISOMOUNT BUSHING	. 2
4	72037-G01	ISOMOUNT CAP	. 2
5	74124-G01	"U" BOLT, 3/8 - 16	. 4
6	00560-G1	WASHER, 3/8"	. 8
7	11098-G5	LOCK NUT, 3/8 - 16	. 8
8			
9	70291-G01	RUBBER BUSHING	. 4
10	14158-G1	SHOULDER BOLT, 3/16 x 3 1/4" LG	. 2
11	00643-G1	WASHER, 3/8"	. 2
12	11098-G5	LOCK NUT, 3/8 - 16	. 2
13			
14	70291-G01	RUBBER BUSHING	. 8
15	70289-G02	SPACER	. 4
16	00429-G2	BOLT, 3/8 - 16 X 3 1/4" LG	4
17	70290-G01	SHACKLE PLATE	4
18	11098-G5	LOCK NUT, 3/8 - 16	4
19			
20	70324-G01	SHOCK ABSORBER	. 2
21	10435-G1	WASHER (SHOCK ABSORBER)	. 8
22	10194-G1	RUBBER BUSHING (SHOCK ABSORBER)	. 8
23	00532-G6	NUT, 3/8 - 24	4

SEATING




SEATING

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	71665-G**	SEAT ASSEMBLY (INCLUDES ITEMS 3 - 25)	. 1
2			
3	71664-G**	SEAT BOTTOM ASSEMBLY (INCLUDES ITEMS 4 - 12)	. 1
4	71602-G**	SEAT BOTTOM COVER	. 1
5	71012-G01	SEAT BOTTOM VINYL TRIM	1
6	71610-G01	SEAT HINGE	2
7	00720-G08	SCREW, #12 - 14 X 1" LG	. 6
8	71701-G01	PASSENGER SIDE HIP RESTRAINT	1
9	71702-G01	DRIVER SIDE HIP RESTRAINT	1
10	00414-G8	BOLT, 1/4 - 20 X 1" LG	. 8
11	00565-G7	LOCK WASHER, 1/4"	. 8
12	00559-G7	WASHER, 1/4"	. 8
13			
14	27546-G**	SEAT BACK ASSEMBLY (INCLUDES ITEMS 15 - 16)	. 1
15	18144-G**	SEAT BACK COVER	. 1
16	18868-G3	PLASTIC SEAT BACK COVER	. 1
17			
18	71662-G01	SEAT BACK SUPPORT BRACKET	2
19	00414-G8	BOLT, 1/4 - 20 X 1" LG	8
20	00567-G7	LOCK WASHER, 1/4"	. 12
21	00559-G7	WASHER, 1/4"	. 12
22	16705-G1	BOLT, 1/4-20 X 1" LG	4
23			
24	71762-G01	SEAL	. 1
25	17074-G1	PAD	. 2

STARTER / GENERATOR

Gasoline Vehicle




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	27065-G01	STARTER / GENERATOR, COMPLETE (INCLUDES ITEMS 2 - 43)	. 1
2	26870-G01	ARMATURE ASSEMBLY (INCLUDES ITEMS 3 - 5)	. 1
3	26871-G01	REAR BALL BEARING	. 1
4	26872-G01	FRONT BALL BEARING	. 1
5	26873-G01	BEARING HOLDER	. 1
6			
7			
8	26875-G01	FIELD COIL	. 1
9	26876-G01	"F" INSULATING BRUSH ASSEMBLY (INCLUDES ITEMS 10 - 13)	2
10	*	NUT	. 2
11	*	LOCK WASHER	. 2
12	*	WASHER	. 2
13	*	INSULATOR	. 1
14	26877-G01	POLE CORE SET SCREW	. 4
15	26878-G01	FRONT COVER	. 1
16	16885-G1	REAR COVER	. 1
17	26880-G01	"A" TERMINAL ASSEMBLY (INCLUDES ITEMS 18 - 23)	2
18	*	TERMINAL	. 2
19	*	INSULATOR	. 2
20	*	INSULATOR	. 2
21	*	WASHER	. 4
22	*	LOCK WASHER	. 4
23	*	NUT	. 4
24			
25	26881-G01	BRUSH HOLDER ASSEMBLY (INCLUDES ITEMS 26 - 28)	1
26	26658-G01	BRUSH	. 4
27	26882-G01	BRUSH SPRING	. 4
28	26883-G01	BRUSH CONNECTOR	. 2
29			
30	26884-G01	KEY	. 1

STARTER / GENERATOR

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	26885-G01	PULLEY	. 1
32	26886-G01	NUT/SCREW ASSEMBLY (INCLUDES ITEMS 33 - 37)	. 1
33	*	NUT	. 1
34	*	LOCK WASHER	. 1
35	*	SCREW	. 3
36	*	SCREW	4
37	*	SCREW	2
38	26887-G01	BRUSH 1 COVER	2
39	26888-G01	BRUSH 2 COVER	3
40	26889-G01	BOLT AND WASHER ASSEMBLY (INCLUDES ITEMS 41, 42)	2
41	*	WASHER	2
42	*	LOCK WASHER	2
43	16896-G1	TERMINAL COVER	. 4


STEERING


Gasoline Vehicle




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70314-G01	STEERING BOX ASSEMBLY, COMPLETE (INCLUDES ITEMS 2 - 10)	. 1
· 2	70299-G01	STEERING GEAR KIT (INCLUDES ITEMS 3 - 10)	. 1
3	*	GEAR PINION	1
4	*	BALL BEARING	1
5	*	EXTERNAL RETAINING RING	1
6	*	STEERING RACK	. 1
7	*	RACK BALL END (WITH NUT)	. 1
8	*	NUT, 7/16 - 20	. 1
9	*	90° GREASE FITTING	. 2
10	*	INTERNAL RETAINING RING	. 1
11			
12	70360-G01	STEERING SHAFT/COLUMN KIT (INCLUDES ITEMS 13 - 25)	. 1
13	14322-G3	STEERING SHAFT	. 1
14	70333-G01	STEERING COLUMN	. 1
15	70226-G01	COUPLING	. 1
16	00550-G1	LOCK NUT, 1/4 - 20	. 2
17	70227-G01	BOLT, 1/4 - 20 X 7/8" LG	2
18	00118-G2	SCREW, #6 - 18 X 1/4" LG	. 1
19	70223-G01	STEERING HOUSING GASKET	. 1
20	00876-G2	BOLT, 3/8 - 16 X 1 1/4" LG	. 3
21	00878-G1	LOCK WASHER, 3/8"	. 3
22	70189-G01	INTERNAL RETAINING RING	. 1
23	17161-G1	BUSHING/SEAL KIT (INCLUDES ITEMS 24, 25)	. 1
24	*	STEERING COLUMN BUSHING	. 1
25	*	SHAFT SEAL	. 1
26			
27	70184-G01	IDLER	. 1
28	70185-G01	FLANGED BEARING	. 1
29	70216-G01	THRUST WASHER, 1 1/2" I.D	. 1
30	70195-G01	THRUST WASHER, 7/8"	. 1

PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
00734-G6	LOCK NUT, 7/8 - 9	1
00798-G8	COTTER PIN, 5/32 X 1 3/4" LG	1
00470-G4	BOLT, 7/16 - 20 X 2 1/2" LG	1
00734-G3	LOCK NUT, 7/16 - 20	1
00462-G7	BOLT, 7/16 - 14 X 7/8" LG	2
00566-G2	LOCK WASHER, 7/16"	2
18325-G1	STEERING WHEEL (INCLUDES ITEM 40)	1
*	HUB COVER	1
14390-G2	LOCK NUT, 5/8 - 18	1
27102-G01	CLIPBOARD	1
00999-G01	SCREW, #8 - 18 X 7/8" LG	2
70074-G01	TIE ROD ASSEMBLY (INCLUDES ITEMS 45 - 50)	2
18434-G2	NUT, 9/16 - 18	2
10387-G2	COTTER PIN, 3/32 X 1" LG	2
50209-G1	SLOTTED NUT, 7/16 - 20	2
50641-G1	RUBBER BOOT	2
10389-G3	GREASE FITTING	2
50209-G1	SLOTTED NUT, 7/16 - 20	1
10387-G2	COTTER PIN, 3/32 X 1" LG	3
10387-G2	COTTER PIN, 3/32 X 1" LG	
	00734-G6 00798-G8 00470-G4 00734-G3 00462-G7 00566-G2 18325-G1 * 14390-G2 27102-G01 00999-G01 70074-G01 18434-G2 10387-G2 50209-G1 50641-G1 10389-G3	00734-G6 LOCK NUT, 7/8 - 9 00798-G8 COTTER PIN, 5/32 X 1 3/4* LG. 00470-G4 BOLT, 7/16 - 20 X 2 1/2" LG. 00734-G3 LOCK NUT, 7/16 - 20









G** Indicates consult Customer Service Department for additional information.			
ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	71711-G03	TRUCK BED ASSEMBLY (40") (MANUAL DUMP) (INCLUDES ITEMS 2 - 9, 20 - 53)	1
2	71719-G01	BED FRAME (40")	1
3	71714-G01	SIDE PANEL (40", PASSENGER SIDE)	. 1
4	71714-G02	SIDE PANEL (40", DRIVER SIDE)	1
5	16705-G3	BOLT, 1/4-20 X 3/4" LG	. 8
6	00915-G1	BONDED WASHER, 1/4"	. 8
7	00559-G7	WASHER, 1/4"	. 8
8	14390-G4	LOCK NUT, 1/4-20	. 8
9	14601-G8	RIVET, 3/8" X 11/16" LG	2
10			
11	71711-G04	TRUCK BED ASSEMBLY (48") (MANUAL DUMP) (INCLUDES ITEMS 9, 12 - 53)	. 1
12	71719-G02	BED FRAME (48")	1
13	71742-G01	SIDE PANEL (48", PASSENGER SIDE)	. 1
14	71742-G02	SIDE PANEL (48", DRIVER SIDE)	1
15	16705-G3	BOLT, 1/4-20 X 3/4" LG	10
16	00915-G1	BONDED WASHER, 1/4"	10
17	00559-G7	WASHER, 1/4"	10
18	14390-G4	LOCK NUT, 1/4-20	10
19			
20	71717-G01	TUBE CAP (1" SQUARE)	2
21	16705-G6	BOLT, 1/4-20 X 1 3/4" LG	4
22	00915-G1	BONDED WASHER, 1/4"	. 8
23	14390-G4	LOCK NUT, 1/4-20	. 4
24			
25	71712-G01	POST (PASSENGER SIDE)	. 1
26	71712-G02	POST (DRIVER SIDE)	1
27	71718-G01	TUBE CAP (1 1/2" SQUARE)	2
28	13437-G8	BOLT, 3/8-16 X 2" LG	4
29	11027-G5	LOCK NUT, 3/8-16	. 4

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30			
31	16705-G3	BOLT, 1/4-20 X 3/4" LG	4
32	00915-G1	BONDED WASHER, 1/4"	4
33	00559-G7	WASHER, 1/4"	4
34	14390-G4	LOCK NUT, 1/4-20	4
35			ļ
36	71732-G01	TAILGATE	1
37	27666-G01	HINGE	. 2
38	01002-G08	BOLT, 1/4-20 X 1" LG	4
39	00559-G7	WASHER, 1/4"	4
40	14390-G4	LOCK NUT, 1/4-20	4
41	71748-G01	TAILGATE KEEPER	1
42	16705-G3	BOLT, 1/4-20 X 3/4" LG	1
43			
44	28288-G01	BED LOCK (PASSENGER SIDE)	1
45	28288-G02	BED LOCK (DRIVER SIDE)	1
46	71763-G01	VINYL TUBING	2
47	00106-G6	SELF-TAPPING SCREW, #12-24 X 3/4" LG	2
48	00915-G1	BONDED WASHER, 1/4"	2
49			
50	71794-G01	LIFT HANDLE	1
51	00976-G08	SCREW, 5/16-18 X 1" LG	2
52	00559-G8	WASHER, 5/16"	2
53	11098-G6	LOCK NUT, 5/16-18	2
54			
55	70396-G01	BED PIVOT	2
56	00764-G2	CARRIAGE BOLT, , 5/16 X 1" LG	6
57	00559-G8	WASHER, 5/16"	6
58	11098-G6	LOCK NUT, 5/16-18	6
59	70291-G01	FLANGED BUSHING	4


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
60	21682-G1	CLEVIS PIN	. 2
61	21683-G1	COTTER PIN	. 2
62			
63	71692-G01	BED LATCH	. 1
64	00559-G7	WASHER, 1/4"	. 4
65	14390-G4	LOCK NUT, 1/4-20	. 4
66	71707-G01	EXTENSION SPRING	. 2
67			
68	71766-G01	CATCH BRACKET	. 2
69	00414-G6	BOLT, 1/4-20 X 3/4" LG	. 4
70	00559-G7	WASHER, 1/4"	. 4
71	14390-G4	LOCK NUT, 1/4-20	. 4
72			
73	71673-G01	PROP BRACKET	. 1
74	71657-G01	PROP ROD	. 1
75	00560-G1	WASHER, 3/8"	. 1
76	15121-G1	WASHER, 3/8" (1 1/4" OD)	. 2
77	10387-G3	COTTER PIN, 3/32 X 3/4" LG	. 2
78			
79	71795-G01	E-Z-GO DECAL (WHITE)	. 1
80	71200-G01	LOAD WARNING LABEL	. 1
81	71771-G01	TILT WARNING LABEL	1
82			
83	74033-G01	BED LINER, 40"	. 1
84	74036-G01	TAILGATE LINER	. 1
85	74033-G02	BED LINER, 48"	. 1



TRUCK BED, ELECTRIC LIFT



TRUCK BED, ELECTRIC LIFT




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	71711-G01	TRUCK BED ASSEMBLY (40") (ELECTRIC DUMP) (INCLUDES ITEMS 2 - 9, 20 - 48)	1
2	71719-G01	BED FRAME (40")	
3	71714-G01	SIDE PANEL (40", PASSENGER SIDE)	
4	71714-G02	SIDE PANEL (40", DRIVER SIDE)	1
5	16705-G3	BOLT, 1/4-20 X 3/4" LG	
6	00915-G1	BONDED WASHER, 1/4"	10
7	00559-G7	WASHER, 1/4"	10
8	14390-G4	LOCK NUT, 1/4-20	10
9	14601-G8	RIVET, 3/8" X 11/16" LG.	. 2
10			
11	71711-G02	TRUCK BED ASSEMBLY (48") (ELECTRIC DUMP) (INCLUDES ITEMS 9, 12 - 48)	1
12	71719-G02	BED FRAME (48")	. 1
13	71742-G01	SIDE PANEL (48", PASSENGER SIDE)	. 1
14	71742-G02	SIDE PANEL (48", DRIVER SIDE)	. 1
15	16705-G3	BOLT, 1/4-20 X 3/4" LG	. 12
16	00915-G1	BONDED WASHER, 1/4"	12
17	00559-G7	WASHER, 1/4"	. 12
18	14390-G4	LOCK NUT, 1/4-20	12
19			
20	71717-G01	TUBE CAP (1" SQUARE)	2
21	16705-G6	BOLT, 1/4-20 X 1 3/4" LG	4
22	00915-G1	BONDED WASHER, 1/4"	
23	14390-G4	LOCK NUT, 1/4-20	. 4
24			
25	71712-G01	POST (PASSENGER SIDE)	1
26	71712-G02	POST (DRIVER SIDE)	. 1
27	71718-G01	TUBE CAP (1 1/2" SQUARE)	. 2
28	13437-G8	BOLT, 3/8-16 X 2" LG	4
29	11027-G5	LOCK NUT, 3/8-16	4


30 31 32 33 34 35 36 37 38 39 40 41 42	16705-G3 00915-G1 00559-G7 14390-G4 71732-G01 27666-G01 01002-G08 00559-G7 14390-G4 71748-G01 16705-G3	BOLT, 1/4-20 X 3/4" LG. BONDED WASHER, 1/4" WASHER, 1/4" LOCK NUT, 1/4-20 TAILGATE HINGE BOLT, 1/4-20 X 1" LG. WASHER, 1/4" LOCK NUT, 1/4-20 TAILGATE KEEPER	4 4 1 2 4
32 33 34 35 36 37 38 39 40 41	00915-G1 00559-G7 14390-G4 71732-G01 27666-G01 01002-G08 00559-G7 14390-G4 71748-G01	BONDED WASHER, 1/4"	4 4 1 2 4
33 34 35 36 37 38 39 40 41	00559-G7 14390-G4 71732-G01 27666-G01 01002-G08 00559-G7 14390-G4 71748-G01	WASHER, 1/4" LOCK NUT, 1/4-20 TAILGATE HINGE BOLT, 1/4-20 X 1" LG WASHER, 1/4" LOCK NUT, 1/4-20	4 4 1 2 4
34 35 36 37 38 39 40 41	14390-G4 71732-G01 27666-G01 01002-G08 00559-G7 14390-G4 71748-G01	LOCK NUT, 1/4-20 TAILGATE HINGE BOLT, 1/4-20 X 1" LG WASHER, 1/4" LOCK NUT, 1/4-20	4 1 2 4
35 36 37 38 39 40 41	71732-G01 27666-G01 01002-G08 00559-G7 14390-G4 71748-G01	TAILGATE HINGE BOLT, 1/4-20 X 1" LG WASHER, 1/4" LOCK NUT, 1/4-20	. 1 . 2 . 4 . 4
36 37 38 39 40 41	27666-G01 01002-G08 00559-G7 14390-G4 71748-G01	HINGE BOLT, 1/4-20 X 1" LG WASHER, 1/4" LOCK NUT, 1/4-20	. 2 . 4 . 4
37 38 39 40 41	27666-G01 01002-G08 00559-G7 14390-G4 71748-G01	HINGE BOLT, 1/4-20 X 1" LG WASHER, 1/4" LOCK NUT, 1/4-20	. 2 . 4 . 4
38 39 40 41	01002-G08 00559-G7 14390-G4 71748-G01	BOLT, 1/4-20 X 1" LG WASHER, 1/4" LOCK NUT, 1/4-20	. 4
39 40 41	00559-G7 14390-G4 71748-G01	WASHER, 1/4" LOCK NUT, 1/4-20	. 4
40 41	14390-G4 71748-G01	LOCK NUT, 1/4-20	
41	71748-G01		
			4
42	16705-G3	······································	. 1
		BOLT, 1/4-20 X 3/4" LG	. 1
43			
44	28288-G01	BED LOCK (PASSENGER SIDE)	. 1
45	28288-G02	BED LOCK (DRIVER SIDE)	. 1
46	71763-G01	VINYL TUBING	. 2
47	00106-G6	SELF-TAPPING SCREW, #12-24 X 3/4" LG	2
48	00915-G1	BONDED WASHER, 1/4"	2
49			
50	70396-G01	BED PIVOT	. 2
51	00764-G2	CARRIAGE BOLT, , 5/16 X 1" LG	. 6
52	00559-G8	WASHER, 5/16"	. 6
53	11098-G6	LOCK NUT, 5/16-18	. 6
54	70291-G01	FLANGED BUSHING	4
55	21682-G1	CLEVIS PIN	2
	21683-G1	COTTER PIN	2
57			
	71795-G01	E-Z-GO DECAL (WHITE)	. 1
	71200-G01		


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY
60			
61			
62	74165-G01	BRACKET	1
63	21320-G3	CIRCUIT BREAKER	1
64	00150-G4	SCREW, #10-24 X 1/2" LG	2
65	00565-G5	WASHER, #10	2
66	00526-G3	NUT, #10-24	. 2
67	25976-G14	WIRE	. 1
68			
69	27680-G01	TOGGLE SWITCH	1
70	27447-G01	TOGGLE GUARD	1
71	10570-G9	RIVET, 1/8" X 11/32" LG	2
72			
73	27612-G02	ELECTRIC ACTUATOR	1
74	27613-G01	SPACER	2
75	14443-G10	CLEVIS PIN, 1/2" X 3" LG	. 1
76	25233-G1	COTTER PIN	2
77	14443-G11	CLEVIS PIN, 1/2" X 1 7/8" LG	1
78			
79	74163-G01	HARNESS	. 1
80	17618-G1	NYLON CLAMP	. 8
81			
82	74033-G01	BED LINER, 40"	. 1
83	74036-G01	TAILGATE LINER	. 1
84	74033-G02	BED LINER, 48"	. 1

TRUCK BED, FLAT & CARGO



TRUCK BED, FLAT & CARGO






ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	71719-G01	BED (40")	1
2	71719-G02	BED (48")	. 1
3			
4	71772-G01	CORNER TUBE	. 2
5	00762-G8	SCREW, 5/16 - 18 X ?? LG	. 4
6	00559-G8	WASHER. 5/16"	. 4
7	00550-G3	NUT, 5/16 - 18	. 4
8			
9	71718-G01	TUBE CAP	. 2
10	71717-G01	TUBE CAP	2
11			
12	70396-G01	BED PIVOT	. 2
13	00764-G2	CARRIAGE BOLT, , 5/16 X 1" LG	. 6
14	00559-G8	WASHER, 5/16"	. 6
15	11098-G6	LOCK NUT, 5/16-18	. 6
16	70291-G01	FLANGED BUSHING	. 4
. 17	21682-G1	CLEVIS PIN	. 2
18	21683-G1	COTTER PIN	. 2
19			
20	71692-G01	BED LATCH	. 1
21	00559-G7	WASHER, 1/4"	. 4
22	14390-G4	LOCK NUT, 1/4-20	. 4
23	71707-G01	EXTENSION SPRING	. 2
24			
25	71766-G01	CATCH BRACKET	. 2
26	00414-G6	BOLT, 1/4-20 X 3/4" LG	4
27	00559-G7	WASHER, 1/4"	. 4
28	14390-G4	LOCK NUT, 1/4-20	. 4
29			
30	71673-G01	PROP BRACKET	. 1


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	71657-G01	PROP ROD	. 1
32	00560-G1	WASHER, 3/8"	. 1
33	15121-G1	WASHER, 3/8" (1 1/4" OD)	. 2
34	10387-G3	COTTER PIN, 3/32 X 3/4" LG	. 2
35			
36	71777-G01	WARNING DECAL	. 1
37	71200-G01	LOAD WARNING LABEL	. 1
38			
39	74157-G01	SIDE RAIL SUPPORT	. 4
40	74161-G01	BACK RAIL SUPPORT	. 2
41	16705-G3	SCREW, 1/4-20 X 3/4" LG	. 12
42	00559-G7	WASHER, 1/4"	. 12
43	14390-G4	NUT, 1/4-20	. 12
44			
45	74167-G01	SIDE CARGO RACK (40") (PASSENGER SIDE)	1
46	74167-G02	SIDE CARGO RACK (40") (DRIVER SIDE)	. 1
47	74168-G01	SIDE CARGO RACK (48") (PASSENGER SIDE)	. 1
48	74168-G02	SIDE CARGO RACK (48") (DRIVER SIDE)	. 1
49	74079-G01	TAILGATE RETAINER BRACKET	. 2
50	00666-G6	SCREW, #10 X 3/4" LG	. 8
51	74162-G03	REAR CARGO RACK	1

WHEEL BRAKE



ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	27942-G01	DRIVER SIDE BRAKE ASSEMBLY (INCLUDES ITEMS 3 - 10)	. 1
2	27942-G02	PASSENGER SIDE BRAKE ASSEMBLY (INCLUDES ITEMS 3 - 10)	. 1
3	27945-G01	BRAKE SHOE KIT (INCLUDES ITEM 4)	. 2
4	*	BRAKE SHOE	2
5	27944-G01	BRAKE SPRING KIT (INCLUDES ITEMS 6 - 10)	2
6	*	UPPER SPRING	1
7	*	LOWER SPRING	1
8	*	PIN	. 2
9	*	CUP AND SPRING	2
10	*	ADJUSTER SPRING	. 1
11	17083-G2	BOLT, 5/16 - 24 X 1" LG	. 8
12	15126-G1	LOCK NUT, 5/16 - 24	. 8
13	21809-G1	INNER BRAKE DRUM WASHER	. 2
14	21807-G1	BRAKE DRUM ASSEMBLY (INCLUDES ITEMS 15 - 16)	. 2
15	*	BRAKE DRUM	. 1
16	19862-G1	LUG BOLT	. 4
17	24939-G2	SPINDLE CAP ADAPTER	. 2
18	21830-G1	OUTER BRAKE DRUM WASHER	. 2
19	00518-G8	SLOTTED NUT, 3/4 - 16	. 2
20	10387-G1	COTTER PIN	. 2
21			
22	12091-G1	SPINDLE CAP	. 2
23			
24	72036-G0 1	PASSENGER SIDE BRAKE CABLE BRACKET	. 1
25	72036-G02	DRIVER SIDE BRAKE CABLE BRACKET	. 1

WHEELS AND TIRES



1 27772-G03 18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, TURF S, (INCLUDES ITEMS 2, 13, 14)	QTY.
2 27772-G07 18 X 8.5 - 8 CARLISLE TIRE, TURF SAVER 3 4 27772-G01 18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, LINKS (INCLUDES ITEMS 5, 13, 14) 5 27772-G05 18 X 8.5 - 8 CARLISLE TIRE, LINKS 6 7 27775-G01 18.5 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRICUDES ITEMS 7, 13, 14) 8 27775-G02 18.5 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRICUDES ITEMS 7, 13, 14) 8 27775-G02 18.5 X 8.5 - 8 CARLISLE TIRE, USA TRAIL 9 10 27784-G01 5.70 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL (INCLUDES ITEMS 11, 14, 15) 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 13 15169-G1 14 11657-G1 WHEEL RIM, 4 LUG, STANDARD	
3 4 27772-G01 18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, LINKS (INCLUDES ITEMS 5, 13, 14)	
4 27772-G01 18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, LINKS (INCLUDES ITEMS 5, 13, 14)	
6 18.5 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TR 7 27775-G01 18.5 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TR 8 27775-G02 18.5 X 8.5 - 8 CARLISLE TIRE, USA TRAIL 9 10 27784-G01 5.70 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL 11 27784-G03 5.70 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 13 15169-G1 13 15169-G1 WHEEL RIM, 4 LUG, STANDARD 14 11657-G1 VALVE STEM	AR
7 27775-G01 18.5 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL 8 27775-G02 18.5 X 8.5 - 8 CARLISLE TIRE, USA TRAIL 9 10 27784-G01 5.70 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 13 15169-G1 WHEEL RIM, 4 LUG, STANDARD 14 11657-G1 VALVE STEM	AR
8 27775-G02 (INCLUDES ITEMS 7, 13, 14)	
9 5.70 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL (INCLUDES ITEMS 11, 14, 15) 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 5.70 - 8 CARLISLE TIRE, USA TRAIL 13 15169-G1 WHEEL RIM, 4 LUG, STANDARD 14 11657-G1 VALVE STEM	
10 27784-G01 5.70 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, USA TRAIL (INCLUDES ITEMS 11, 14, 15) 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 13 15169-G1 14 11657-G1 VALVE STEM	AR
11 27784-G03 (INCLUDES ITEMS 11, 14, 15) 11 27784-G03 5.70 - 8 CARLISLE TIRE, USA TRAIL 12 13 15169-G1 13 15169-G1 WHEEL RIM, 4 LUG, STANDARD 14 11657-G1 VALVE STEM	
12 13 15169-G1 WHEEL RIM, 4 LUG, STANDARD 14 11657-G1 VALVE STEM	AR
13 15169-G1 WHEEL RIM, 4 LUG, STANDARD 14 11657-G1 VALVE STEM	AR
14 11657-G1 VALVE STEM	
	AR
15 33678-G01 WHEEL RIM, 4 LUG	AR
	AR

SPECIAL TOOLS

SPECIAL TOOLS LISTING

SPECIAL TOOLS

SPECIAL TOOLS

Part No.

PULLER, DRIVE CLUTCH	19779-G2
PULLER, FLYWHEEL	27111-G01
CAM PULLEY TOOL	27851-G01
CURRENT INDICATOR	16489-G2
MULTI-METER, DIGITAL	27481-G01
CRIMPING TOOL	27765-G01
SLIDE HAMMER (AXLE/HUB REMOVAL)	15947-G1
SLIDE HAMMER (AXLE REMOVAL ONLY)	
TACHOMETER	
FEELER GAUGE	72525-G01
COMPRESSION TESTER	72524-G01

OIL, 10W-30

5 GALLONS	
12 QUART CASE	
55 GALLON DRUM	

PAINT

.6 OUNCE BRUSH ON PAINT	- HUNTER GREEN	

ACCESSORIES LISTING

ACCESSORIES

ACCESSORIES LISTING

KIT NO.

HUB CAP - 8" CHROME	14913-G**	See Kit Instruction Sheet 28244
HUB CAP - 6" CHROME	16042-G**	See Kit Instruction Sheet 28244
HUB CAP - GOLD SPOKE	19241-G**	See Kit Instruction Sheet 28244
HUB CAP - SILVER SPOKE	19241-G**	See Kit Instruction Sheet 28244
RAMP KIT	28334-G01	See Kit Instruction Sheet 28335
ELECTRIC DUMP KIT	74164-G02	See Kit Instruction Sheet 74166
WINDSHIELD KIT (2 BEND, CLEAR)	75041-G03	See Kit Instruction Sheet 75043
WINDSHIELD KIT (2 BEND, TINTED)	75041-G04	See Kit Instruction Sheet 75043
WINDSHIELD KIT (4 BEND, CLEAR)	75041 - G05	See Kit Instruction Sheet 75043
WINDSHIELD KIT (4 BEND, TINTED)	75041-G06	See Kit Instruction Sheet 75043
LIGHT AND TURN SIGNAL	75107-G02	See section 'N'
ASH TRAY KIT	75109-G02	See Kit Instruction Sheet 75110
HOUR METER	75114-G02	See Kit Instruction Sheet 75119
REAR VIEW MIRROR KIT	19528-G2	See Kit Instruction Sheet 75162
BALL HITCH KIT	75326-G02	See Kit Instruction Sheet 75328
CLEVIS HITCH KIT	75327-G02	See Kit Instruction Sheet 75329
LIGHT BAR KIT WITH FLOOD LIGHT	75354-G01	See Kit Instruction Sheet 75348
LIGHT BAR KIT WITH BEACON	75354-G02	See Kit Instruction Sheet 75348
LIGHT BAR KIT WITH FLOOD/BEACON	75354-G03	See Kit Instruction Sheet 75348
SUN TOP KIT	75350-G01	See Kit Instruction Sheet 75351
FRONT BUMPER KIT	74041-G02	See Kit Instruction Sheet 75355
WEATHER ENCLOSURE	75367-G01	See Kit Instruction Sheet 75368
SPARK ARRESTOR KIT	25747-G01	


ACCESSORIES ILLUSTRATED


ACCESSORIES

Notes:	
	<u> </u>
•	
	· · · · · · · · · · · · · · · · · · ·

			k							REV -	PG. 1 OF 1	
	DESCRIPTION	8" CHROME HUBCAP	8" CHROME HUBCAP SET	6" CHROME HUBCAP	6" CHROME HUBCAP SET	GOLD SPOKE HUBCAP	GOLD SPOKE HUBCAP SET	SILVER SPOKE HUBCAP	SILVER SPOKE HUBCAP SET		A DRAWING NO. 28244	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855
	PART NO.	14913-G1	14913-G2	16042-G1	16042-G2	19241-G2	19241-G4	19241-G1	19241-G3	ATION	REV BY REV DATE	388, AUGUSTA,GA.
dy	ατγ	-	4	-	4	-	4		4	ISTALL	CGT 02/07/95	P.O. BOX
8" CHROME HUBCAP	ITEM	-	2	ო	4	പ	9	7	ω	OVER IN	DRN BY ORIG DATE	FRON, INC.
8" CHRO										TITLE WHEEL COVER INSTALLATION		E-Z-GO DIVISION OF TEX
the set of							GOLD / SILVER SPOKE HUBCAP					REPLACEMENT PARTS.

·





READ ALL INSTRUCTIONS BEFORE PROCEEDI	EDING.		
A. REMOVE EXISTING TAILGATE	E. FINAL ASSEMBLY	:MBLY	
 Engage parking brake. Remove tailgate, right and left hinges, and related hardware. Leave chains and hooks attached to truck bed. Retain all parts for possible future use. 		 Insert left pivot shaft of the upper ramp into the driver side support (item 5) as shown in illustration on first page. Place passenger side support (item 16) onto right pivot shaft of the upper ramp and mount support to the right side of the truck bed using procedure in step 2 of TRUCK BED ASSEMBLY. 	rt (item 5) as e upper ramp re in step 2 of
B. TRUCKBED ASSEMBLY	3. Ramp is he	Ramp is held in upright (stored) position with tailgate hooks.	
1. Locate right and left corner posts on the truck bed. Remove lower outside bolts and rear lower panel truss head screw.	e lower outside bolts		
 Attach driver's side ramp support (item 5) to the side of the truck bed securing with hardware (items 6, 9 and 10). See Detail B. Using hardware (items 20, 14, and 21), secure bracket (item 5) to corner post. Extra spacers may be needed between bracket and post to fill gap as shown in Detail B. 	e truck bed securing dware (items 20, 14, cers may be needed		
3. The mounting bracket for the opposite post will be added at final assembly.	t final assembly.		
C. LOWER RAMP ASSEMBLY			
1. Place <i>NON-WELDED</i> side (see Detail A) of left pivot (item 3) flush against the side of the lower ramp (item 2). Align mounting holes and fasten securely with hardware (item 7, 9 and 10).	 3) flush against the fasten securely with 		
 The right pivot (item 1) is to be mounted using the same procedure as the left pivot except a washer (item 8) <i>must</i> be added between the ramp and the pivot. 	procedure as the left pramp and the pivot.		
D. UPPER TO LOWER RAMP ASSEMBLY			
1. Make certain the top surface (side with mesh) of each ramp is facing outwards.	o is facing outwards.		
 Place one pivot spacer (item 12) inside each slot of pivot brackets and secure lower ramp to upper ramp with hardware (items 13, 14, and 21) as shown in illustration on first page. 	brackets and secure and 21) as shown in		
THE SYMBOL	TITLE TRUCK RAMP FIELD KIT	T (48" WIDE BED)	REV -
THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. BETAIN THIS DOCIMENT TO FACILITATE THE ORDERING OF	CALCE LINKION DAN BY J.RICE 09/01/95	REV BY REV DATE A DRAWING NO. 28335	PG. 3 OF 4
REPLACEMENT PARTS.	Ц.Х.	GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855.	

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 28334-G01

5/16-18 X 1 Lg. Screw	Item 8					
	5/16 Heavy Washer Cty. 4	ITEM	ατγ	PART NO.	DESCRIPTION	
		-	-	20252-G1	PIVOT, PASSENGER SIDE	
Ltem 7		0 0		20257-G2	RAMP, LOWER	
5/16-18 X 1 3/4 Lg. Screw Qty. 4	\bigcirc	n 4		20252-GZ 20264-G1	PIVUI, UNIVER'S SIUE RAMP, UPPER	
		· ي	y	28331-G02	SUPPORT, RAMP, DRIVER'S SIDE	SIDE
	5/16 Light Washer	9	M 4	00438-G8 00271-G6	BOLT, 5/16-18 X 1 LG. BOLT 5/16-18 X 1 3/4 I.G.	
A1111411111111111111111111111111111111	2.65	80	4	00569-G2	WASHER, 5/16, HEAVY	
3/8-16 x 2 Lg. Screw		0	8	00559-G8	WASHER, 5/16, LIGHT	
Qty. 2		10	9	11098-G6	NUT, LOCK, 5/16-18	
	\hat{C}	÷ ÷	c	00075 01		
		<u>v</u> ç	v c	19-0/202		
	Item 10 5/16-18 Lock Nut	5 1	1 0	00562-G1	DOLI 3/0-10 A 2 LG. WASHER, 3/8	
Item 20 3/8-16 x 2 3/4 Lg. Screw	Qty. 6	15				
Qty. 2		16	-	28331-G01	SUPPORT, RAMP, PASSENGER SIDE	ER SIDE
		17	· · · · · ·			
		19 20	2	00428-G6	BOLT, 3/8-16 X 2 3/4 LG.	- <u>,</u>
	Item 21	21	4	11098-G5	NUT, LOCK, 3/8-16	
Pivot Spacer 3/8 Washer Cty. 2 Cty. 10	3/8-16 Lock Nut Qty. 4					
· 1						
						HEV -
THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCIMENT TO FACILITATE THE ORDERING OF	EZZ C D TEXTRON	DRN BY ORIG DATE	J.RICE 09/01/95	REV BY REV DATE	A DRAWING NO. 28335	PG. 4 OF 4
REPLACEMENT PARTS.		RON, INC., P	.O. BOX (388, AUGUSTA,GA	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855	
]

HARDWARE SHOWN ACTUAL SIZE

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 74164-G02

READ ALL INSTRUCTIONS BEFORE PROCEEDING.

TOOL LIST	QTY. REQUIRED
Flat Screwdriver	1
Wrench, 7/16"	1
Wrench, 3/8"	1
Rivet Gun	1
Needle Nose Pliers	1

TOOL LIST	QTY. REQUIRED
Phillips Screwdriver	1
Open End Wrench, Insulated, 1/2"	1
Wrench, 1/4"	1
Shop Rag	1




BEFORE INSTALLING THE ELECTRIC DUMP KIT, THE FOLLOWING STEPS MUST BE TAKEN:

- 1. Place vehicle on level floor and engage the parking brake.
- 2. Raise and secure seat.
- 3. Using an insulated wrench, disconnect the battery ground cable and cover negative battery terminal (-) with a shop rag. (See Fig. 1)



TO PREVENT PERSONAL INJURY, USE AN INSULATED WRENCH TO DISCONNECT AND RECONNECT THE BATTERY GROUND CABLE.



A WARNING A

TO PREVENT PERSONAL INJURY, ENSURE BED IS PROPERLY SUPPORTED IN RAISED POSITION BEFORE CONTINUING WITH THE FOLLOWING PROCEDURES.

5. Remove and discard the latch assembly from the front of the dump bed. (See Fig. 2)





Fig. 2 Latch Assembly Removal

6. Remove and discard the bed prop assembly from the driver side rear fender. (See Fig. 3)



A. TOGGLE SWITCH MOUNTING (See Fig. 4)

- 1. Attach circuit breaker (Item 2) to mounting bracket (Item 1) using screw (Item 3), lock washer (Item 4) and nut (Item 5).
- 2. Remove outer nut from toggle switch (Item 6) and insert the toggle lever through circuit breaker mounting bracket and into the seat wrap hole as illustrated in Fig. 4.
- 3. Place the toggle switch guard (Item 7) over the toggle switch lever and attach with outer nut. (Do not tighten)
- 4. Secure the toggle switch guard and circuit breaker mounting bracket to seat wrap with rivets (Item 8).
- 5. Adjust the toggle switch nut behind the bracket to position the tip of the toggle switch lever a distance of 1/16" or less beyond the toggle switch guard and tighten nut securely.
- 6. Attach red wire (Item 9) to circuit breaker and toggle switch as shown in Fig. 4.




Fig. 4 Toggle Switch Installation

B. CONTROL HARNESS ROUTING (See Fig. 5)

- 1. Route the control harness (Item 10), beginning at the toggle switch, down the seat frame support on the driver side of the vehicle as illustrated in Fig. 5. *Leave enough slack in the control harness for connecting terminals to toggle switch.*
- 2. Secure the control harness to the seat frame support with a nylon clamp (Item 11) as shown in Fig. 5.
- 3. Route the control harness toward the rear of the truck, on the inside of the frame rail, to the rear cross member as shown.
- 4. Secure the control harness to the frame using nylon clamps in the locations shown in Fig. 5

TITLE ELECTRIC DUN		LATION IN	NSTRUCTIONS			REV -
EZGO TEXTRON		J.RICE 2/15/95	REV BY REV DATE	DRAWING NO.	74166	PG. 3 OF 6
E-Z-GO DIVIS	ION OF TEXTRO	ON, INC., P.O. E	3OX 388, AUGUSTA,GA. 30903	-0388, 1-800-448	3-7476	





Fig. 5 Control Harness Routing


C. WIRING THE TOGGLE SWITCH (See Fig. 6)

- 1. Connect the white wire from the actuator to the toggle switch as shown.
- 2. Connect the red wire from the actuator to the toggle switch.
- 3. Connect the black (ground) wire from the battery to the toggle switch.
- 4. Connect the red wire from the battery to the circuit breaker as shown.



D. INSTALLING THE ELECTRIC ACTUATOR

- 1. Place the electric actuator, item 1 into the cylinder mount oriented as shown, and insert clevis pin (Item 13) through the cylinder mount and electric actuator. Secure with spring pin (Item 16).
- 2. Connect the control harness to the electric actuator.
- 3. Using an insulated wrench, reconnect battery ground cable. (See Fig. 1)
- 4. Extend actuator to full length by operating toggle switch lever.
- 5. Locate the appropriate holes in the center support angle of the truckbed frame.
- 6. Place one spacer (Item 15) on each side of electric actuator and insert 3" clevis pin (Item 14) through the center supports of the truckbed frame, the spacers and the electric actuator. (See Fig. 7)
- 7. Secure clevis pin with spring pin (Item 16).




KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
1	1	74165-G01	CIRCUIT BREAKER MOUNTING BRACKET
2	1	21320-G3	CIRCUIT BREAKER
3	2	00150-G4	SCREW, #10-24 X 1/2" LG.
4	2	00565-G5	LOCK WASHER, #10
5	2	00526-G3	NUT, #10-24
6	1	27680-G01	TOGGLE SWITCH
7	1	27447-G01	TOGGLE SWITCH GUARD
8	2	10570-G9	RIVET, 5/32" X 9/16" LG.
9	1	25976-G14	RED WIRE
10	1	74163-G01	CONTROL HARNESS
11	8	17618-G1	NYLON CLAMP
12	1	27612-G02	ELECTRIC ACTUATOR
13	1	14443-G11	CLEVIS PIN, 1/2" X 1 7/8" LG.
14	1	14443-G10	CLEVIS PIN, 1/2" X 3" LG.
15	2	27613-G01	SPACER
16	2	25233-G1	SPRING PIN


TITLE ELECTRIC DUM	P INSTA		N INSTRUCTIONS			REV -
	DRN BY ORIG DATE	J.RICE 12/15/95	REV BY REV DATE	DRAWING NO.	74166	PG. 6 OF 6
E-Z-GO DIVISI	ON OF TEXT	RON, INC., P	.O. BOX 388, AUGUSTA,GA.	. 30903-0388, 1-800-448	8-7476	

* CONTACT SERVICE PARTS FOR AVAILABILITY.							
ш	0 BOTTOM 10.	8		0 0			
 INSERT THE SPACERS, ITEM 4 INTO THE RUBBER GROMMETS. INSERT THE PLUG BUMPERS, ITEM 5 INTO THE CENTER HOLES OF THE WINDSHIELD, ITEMS 1, 2 OR THE TOP OF WINDSHIELD, ITEMS 9 OR 10. 	MMETS. ER HOLES OF THE ITEMS 9 OR 10.	4	No. and Windows		c ©		ω
4. PLACE THE WINDSHIELD AGAINST THE FRONT STRUT WITH TAPERED END AT THE TOP.	WITH THE SMALL				8 7 4	8 -0	
 INSERT THE BOLTS, ITEM 6 THRU WINDSHIELD AND THE FRONT STRUT AND SECURE WITH WASHERS, ITEM 7 AND LOCK NUTS, ITEM 8. 	HE FRONT STRUT , ITEM 8.	ى م	al part of	°- 1,2, 11		9,10	
e			DETAIL A	A	-	DE I AIL B	
	1, 2, 11 - DETAIL A 9, 10 - DETAIL B						
		ITEM	ατγ	PART NO.	DESCRIPTION	z	
		-	-	75021-G01	WINDSHIELD	WINDSHIELD, CLEAR, 2 BEND	
		ი თ	- 4	75021-G02 72147-G01	WINDSHIELD, TINTEI GROMMET. RUBBER	windshield, Tinted, 2 Bend Grommet. Rubber	0
		4	4	23726-G7	SPACER		
		ى م	2	75124-G01	BUMPER, PLUG	UG	
		91	4 4	16705-G6	SCREW, 1/4-2	SCREW, 1/4-20 X 1 3/4 LG.	
		~ 00	1 4	00891-G2	NUT, LOCK, 1/4-20	/4-20	
		6	-	75203-G01	WINDSHIELD	WINDSHIELD, CLEAR, 4 BEND	
		10		75203-G02	WINDSHIELD	WINDSHIELD, TINTED, 4 BEND	_
		5	-	75021-G03	WINDSHIELD	WINDSHIELD, CLEAR, 2 BEND, OASIS	, OASIS
THE SYMBOL CREFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT		LSNI DT	TALLAT	NOI			rev d
SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	EZZG TEXTRON	DRN BY ORIG DATE	L WEBB 12/17/93	REV BY J.E REV DATE 02/	J.Brand 02/23/96	DRAWING NO. 75043	PG. 1 OF 2
HEPLACEMENI PARIS.	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855	TRON, INC.,	P.O. BOX 3	188, AUGUSTA,G/	A. 30913-2699, 1-800	-241-5855	


NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75041-G0*



NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75109-G02	NO. 75109-G02						
READ ALL INSTRUCTIONS BEFORE PROCEEDIN	EDING.					/	
 INSERT THE ASH TRAY, ITEM 1 INTO THE GASKET, ITEM 2 UNTIL THE GAS- KET HOOKS OVER THE FLANGES ON THE TOP AND BOTTOM OF THE ASH TRAY. 	12 UNTIL THE GAS- ITTOM OF THE ASH						
 USING BRACKET, ITEM 3 AS A TEMPLATE, INSERT THE (4) SELF DRILLING SCREWS, ITEM 4. LOCATE BRACKET APPROXIMATELY AS SHOWN IN ILLUSTRATION. 	(4) SELF DRILLING LY AS SHOWN IN						
3. SNAP THE ASH TRAY INTO THE BRACKET.			∾^				
							σ
		ITEM	ατγ	PART NO.	DESCRIPTION		
		-		27731-G01	ASH TRAY		
		2 0	- -	27736-G01 76108-G01	GASKET, ASH TRAY BBACKET ASH TBAV	AY Dav	-
		24	- 4	00100-G4	SCREW, 10-16 X 1/2" LG.	1/2" LG.	
THE SYMBOL CREFERS TO A NOTE CORRESPONDING TO	TITLE ASH TRAY INSTALLATION	INSTAL	LATIO	z			REV -
SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF		DRN BY ORIG DATE	L WEBB 01/21/94	rev by Rev date	A NO.	DRAWING NO. 75110	PG. 1 OF 1
REPLACEMENT PARTS.	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855	RON, INC., F	.O. BOX 3	88, AUGUSTA,GA	. 30913-2699, 1-800-241-	5855	



READ ALL INSTRUCTIONS BEFORE PROCEEDING. A. ASSEMBLE HOUR METER	READ ALL INSTRUCTIONS BEFORE PROCEEDING. A. ASSEMBLE HOUR METER					
 Insert Hour Meter (item 1) through Bracket (item 2), positioned as shown. Using hardware supplied with the Hour Meter, secure Hour Meter to Bracket. Attach Harness (item 5) to Hour Meter as shown, Yellow wire to Positive (+) terminal and Black wire to Negative (-) terminal of Hour Meter. 	s shown. r to Bracket. Positive (+) ter-					
 B. ATTACH HOUR METER ASSEMBLY 1. Locate predrilled holes in the driver's side seat support and secure the Hour Meter Assembly using Bolts (item 3) and Nuts (item 4) as shown. 	ecure the Hour					
C. CONNECT TO ELECTRONIC SPEED CONTROL 1. Locate the cables from the Electrical Control Panel to the batteries. Disconnect	ies. Disconnect					
2. Remove the nut securing the cover on the Electrical Control Panel, and remove the cover from the Electrical Control Panel.	el, and remove					
Remove the nut and lock washer from the left solenoid terminal and low wire from Harness to terminal and reinstall lock washer and nut.	and install Yel- nut.					
 Repeat procedure on right terminal for Black wire. Replace cover and reinstall nut. 						
6. Reconnect Electrical Control Panel cabels to batteries as connected earlier.	sted earlier.					
	L	ITEM	ατγ	PART NO.	DESCRIPTION	
	Į	-	-	21573-G1	METER, HOUR	
		N 0	- c	74019-G01	BRACKET, HOUR METER	
) 4	1 01	11098-G7	NUT, #10-24	
		ഹ	-	75117-G01	HARNESS, HOUR METER	æ
TE CORRESPONDING TO		ER INS	TALLA	TION		REV -
THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. BETAIN THIS DOCIMENT TO EACH ITATE THE ORDERING OF		DRN BY ORIG DATE	J.RICE 02/21/95	REV BY REV DATE	A DRAWING NO. 75119	PG. 2 OF 2
	GO DIVISION OF TEXTR	RON, INC.,	P.O. BOX (388, AUGUSTA,GA	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855	




NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO.	NO. 19528-G2					
READ ALL INSTRUCTIONS BEFORE PROCEEDI	EDING.					
1. DISCARD PLASTIC MOUNTING BRACKETS AND ADHESIVE WITH KIT. THESE ITEMS ARE USED IN OTHER APPLICATIONS.	HESIVE SUPPLIED TIONS.					
2. REMOVE THE FRONT TOP HARDWARE FROM THE FRONT IS NOT NECESSARY TO REMOVE TOP.	ONT TOP STRUT. IT					
3. LOCATE AND DRILL A .147 DIA. HOLE (#26 DRILL) THROUGH CENTER OF FRONT TOP STRUT (INSIDE SURFACE ONLY). SEE DETAIL A.	ough center of Aila.					
4. USING SCREW, ITEM 3 FASTEN SUPPORT BRACKET, ITEM 5 TO FRONT TOP STRUT AS SHOWN IN DETAIL A.	ITEM 5 TO FRONT					
5. LOOSEN SETSCREW SUPPLIED WITH MIRROR.						
6. SLIDE MIRROR, ITEM 1 ONTO BRACKET AND TIGHTEN NOT OVERTIGHTEN. DAMAGE TO MIRROR WILL OCCUR.	EN SETSCREW. <i>DO</i> R.					
7. REINSTALL THE TOP ONTO THE FRONT TOP STRUT. TIGHTEN HARDWARE TO 3 - 5 FT. LBS. TORQUE.	GHTEN HARDWARE					
		ITEM	ατγ	PART NO.	DESCRIPTION	
		+ 0	-	19496-G1	MIRROR, REAR VIEW	
		1 M	 F-	19527-G1	SCREW, STAINLESS STEEL, SELF TAP- PING, #8 - 32 x 5/8 LG.	LF TAP-
		4 ư	-	19502-G2		
				10001		
THE SYMBOL \triangleleft refers to a note corresponding to	TITLE REAR VIEW MIRROR INSTALLATION INSTRUCTIONS	RROR	INSTA	LLATION IN		REV -
THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. DETAIN THIS DOCIMENT TO EACH ITATE THE OBDEDING OF		DRN BY ORIG DATE	CGT 05/16/94	rev by Rev date	A DRAWING NO. 75162 PG.	3. 2 OF 2
REPLACEMENT PARTS.	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855	N, INC., P	.O. BOX 3	38, AUGUSTA,GA	. 30903-0388, 1-800-241-5855	


	READ ALL INSTRUCTIONS B	EFORE PROCEEDII	NG.	
TOOL LIST	QTY. REQUIRED	TOOL LIST	QT	. REQUIRE
Socket, 9/16"		Wrench,9/16"		
Ratchet		Torque Wrench		
INSTALLIN	а нітсн			
1. Position h	itch under rear bumper as shown and align	holes in hitch with holes	in bumper.	
2. Insert bolt secure with	through bumper and hitch from the top ar h nut. Finger tighten nut at this time.	nd place flat washer and l	lock washer on bolt a	as shown a
3. Repeat pr	ocess in other three holes.			
	tch with bumper and tighten nuts to 31 ft.lbs	s. torque.		
) Vehic	le Rear Bumper	
			le Rear Bumper	
ITEM	KIT CON			
	Image: Constrained state Image: Constrained state Image: Constrained state	TENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG WASHER, 3/8" LOCK WASHER, 3/8"		
1 2 3 4 5	Image: Constrained state Image: Constrained state Image: Constrained state	TENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG WASHER, 3/8" LOCK WASHER, 3/8"		REV -

.

	READ ALL INSTRUCTIONS B	BEFORE PROCEEDING.		
FOOL LIST	QTY. REQUIRED	TOOL LIST	QTY.	REQUIRE
Socket, 9/16"		Wrench,9/16"		••••••
Ratchet	1	Torque Wrench		•••••
A. INSTALLING HITC	н			
. Position hitch und	der rear bumper as shown and align	holes in hitch with holes in bump	ber.	
	h bumper and hitch from the top ar Finger tighten nut at this time.	nd place flat washer and lock wa	sher on bolt as	shown an
3. Repeat process in	n other three holes.			
	bumper and tighten nuts to 31 ft.lbs	s. torque.		
		Vehicle Rear B	umper	
			Ø	
ITEM	3 6 4 9 5 9 7 8 KIT CON	TENTS		
ITEM QT	3 6 4 5 7 0 KIT CON Y PART NO.	ITENTS DESCRIPTION		
	3 6 0	ITENTS DESCRIPTION HITCH		
11	3 6 4 5 7 0 KIT CON Y PART NO.	ITENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG.		
11 24 34	3 6 0	ITENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG. WASHER, 3/8" LOCK WASHER, 3/8"		
11 24 34	3 6 4 5 6 4 5 6 4 5 6 7 7 6 6 7 7 7 6 7 <th7< th=""></th7<>	ITENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG. WASHER, 3/8" LOCK WASHER, 3/8" NUT, 3/8-16		
11 24 34 44 54 61	3 6 4 5 7 6 9 6 9 6 9 7 <th7< th=""></th7<>	ITENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG. WASHER, 3/8" LOCK WASHER, 3/8" NUT, 3/8-16 CLEVIS PIN		
11 24 34 44 54 61 71	3 6 4 5 6 4 5 6 4 5 6 7 7 6 6 7 7 7 6 7 <th7< th=""></th7<>	ITENTS DESCRIPTION HITCH BOLT, 3/6-16 X 1 1/2" LG. WASHER, 3/8" LOCK WASHER, 3/8" NUT, 3/8-16 CLEVIS PIN		REV -


.






READ ALL INSTRUCTIONS BEFORE PROCEEDING.		3. Adjus the sv	Adjust the har the switch plat	less as necessal e and remove an	Adjust the harness as necessary to place the switch connectors at the rear of the switch plate and remove any excessive tightness or looseness in the har- ness routing	ne rear of the har-
A. INSTALLING THE WORK LIGHT STRUTS (See Detail A)		4. Using	the nylo	n clamps (item 16	Using the nylon clamps (item 16), secure the switch harness to the frame in	rame in
1. Using a flexible wire, fish the light harness (item 11) down through the driver side strut (item 2), being careful not to kink the harness as it is being inserted.	t is being inserted.	three	three places.			
first pair of connectors is pulled inside the top end of the strut.		ITEM	ατγ	PART NO.	DESCRIPTION	
2. Pull seat bottom forward to gain access to frame. Remove hole	tole plugs from filler	۰	-	75352-G01	WORK LIGHT STRUT, PASSENGER SIDE	ER SIDE
		2	+	75352-G02	WORK LIGHT STRUT, DRIVER SIDE	IDE
3. At driver side of vehicle, thread the end of strut with the three connectors	se connectors	ო	9	00685-G7	BOLT, 5/16 - 18 X 3/4" LG.	
through hole in tiller panel and insert short leg of strut through hole in panel and rest led on frame rail (To be properly nositioned the short led of strut should be	in hole in panel and	4	12	00660-G8	WASHER, 5/16"	
pointed toward the front of the vehicle and the longer upper leg should be	leg should be	പ	4 (11098-G6	LOCK NUT, 5/16 - 18	
			، ۱	75353-601		
4. Being careful not to chafe the harness inside the strut, insert bolt (item 3) with washer (item 4) through hole in lower strut leg and through hole in frame.	t bolt (item 3) with hole in frame.	. 8		75363-G01	COVER PLATE	
Secure with washer (item 4) and lock nut (item 5). (Two places each side)	ces each side)	ი		75349-G01	LIGHT SWITCH PLATE	
5. Repeat steps 3 and 4 on other side of vehicle. (Passenger side	strut does not	10	2	71055-G01	RIVET, 3/16" X 3/8" LG.	
have harness.)		11	-	75346-G01	LIGHT HARNESS	
		12	-	75347-G01	SWITCH HARNESS	
B. INSTALLING THE LIGHT SWITCH PLATE (See Detail B)	B)	13		33201-G02	STROBE LIGHT MOUNT	
1. Position the left edge of the light switch plate (item 9) 4 1/2" left	left of the center of	14	2	16705-G3	SCREW, 1/4 - 20 X 3/4" LG.	
the steering column and the top edge 3/4" up from the bottom of the dash.	m of the dash.	15	2	14390-G4	LOCK NUT, 1/4 - 20	
	the dash.	16	ო	17618-G1	CLAMP, NYLON	
2. Attach the light switch plate to the dash using the rivets (item 10) provided.		17				
		18	N	20209-G2	WORK LIGHT (RECTANGULAR)	
C. ROUTING THE SWITCH HARNESS (See Detail C)		19	-	17317-G1	LIGHT SWITCH	
1. Connect the white lead from the light harness (item 11) to the white terminal		20	•	20053-G1	WIRE, RED	
from the switch harness (item 12), the yellow lead to the yellow terminal and the black lead to the black terminal.	the	21	. –	17902-G1	TAB ADAPTER	
2. Being careful not to chafe the switch harness, route the switch harness around		23	-	20394-G1	STROBE LIGHT	
the battery (toward the center of the vehicle), down through the hole in the bat-		24	ო	00379-G4	SCREW, #10 - 24 X 1/2" LG.	- i ,
tery tray in front of the battery, through the oval hole in the frame cross member,	cross member,	25	ო	11098-G7	LOCK NUT, #10 - 24	
Inrough the oval hole in the front cross member and up though t floor at the stearing column		26	-	17317-G1	LIGHT SWITCH	
		27	-	20053-G1	WIRE, RED	
		28	-	17902-G1	TAB ADAPTER	
THE SYMBOL CREFERS TO A NOTE CORRESPONDING	TITLE WORK LIGHT MOUNTING INSTRUCTIONS	NOM -	NTING	INSTRUCT	ONS	REV -
TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS		DRN BY ORIG DATE	J.RICE 12/07/95	REV BY REV DATE	A DRAWING NO. 75348	PG. 3 OF 5
LISUS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDER-	E-Z-GO DIVISION OF TEXTRON	N, INC., F	O. BOX	388, AUGUSTA,GA	-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855	


NOTE: TO ORDER EITHER OF THESE FIELD KITS, REQUEST 75354-G0*.



.



NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST 75350-G01 READ ALL INSTRUCTIONS BEFORE PROCEEDING. A. REAR STRUTS (REFER TO DETAIL A) 1. PULL SEAT BOTTOM FORWARD TO GAIN ACCESS BELOW. REMOVE HOLE PLUG FROM PANELS. 2. INSERT TUBE END CAP (ITEM 18) IN TOP (LONG) END OF STRUT (ITEM 2 AND 3).	75350-G01 DING. BELOW. REMOVE DF STRUT (ITEM 2	With For 3. Tigh 4. Tigh 5. Tigh	I WASHEI INSTALL TEN ALL TEN ALL TEN ALL	WITH WASHER, (ITEM 15), AND L FOR INSTALLATION SEQUENCE. TIGHTEN ALL SUN TOP HARDW/ TIGHTEN ALL REAR STRUT HAR TIGHTEN ALL FRONT STRUT HA	WITH WASHER, (ITEM 15), AND LOCK NUT, (ITEM 16). SEE ILLUSTRATIONS FOR INSTALLATION SEQUENCE. TIGHTEN ALL SUN TOP HARDWARE TO 3 - 5 FT. LBS. TORQUE. TIGHTEN ALL REAR STRUT HARDWARE TO 13 - 15 FT. LBS. TORQUE. TIGHTEN ALL FRONT STRUT HARDWARE TO 17 - 19 FT. LBS. TORQUE.	RATIONS QUE.
 INSERT SHORT LEG OF REAR STRUT (ITEM 2) THROUGH HOLE. POSI- TION STRUT SO THAT LOWER (SHORT) LEG IS POINTING TOWARD THE FRONT OF THE VEHICLE, AND UPPER (LONG) LEG IS POINTING TOWARD THE CENTER OF THE VEHICLE. PLACE BOLT (ITEM 5) WITH WASHER (ITEM 4) THROUGH HOLE AT THE BOTTOM OF THE STRUT, AND THE HOLE IN THE FRAME. SECURE STRUT WITH WASHER (ITEM 4) AND NUT (ITEM 6). REPEAT STEPS 2 AND 3 ON OTHER SIDE OF VEHICLE. 	JGH HOLE. POSI- NG TOWARD THE EG IS POINTING GH HOLE AT THE SECURE STRUT					
6. PLACE BOLT (ITEM 5) WITH WASHER (ITEM 4) THROUGH SLOT IN FRAME AND STRUT THEN SECURE WITH WASHER (ITEM 4) AND NUT (ITEM 6)		ITEM	ατγ	PART NO.	DESCRIPTION	
7. REPEAT STEP 6, ON OTHER SIDE OF VEHICLE.		Ļ	1	27069-G01	TOP, SUN	
B. FRONT STRUT - NOTE: DISCARD TUBE SPACER IF VEHI	EHICLE IS	N 03		75343-G01 75343-G02	STRUT, REAR, DRIVER SIDE STRUT REAR PASSENGER SIDE	Ц
		4	8	00571-G2	WASHER, 5/16"	1
1. USING A //32" ALLEN WHENCH, HEMOVE THE FOUR ALLEN FROM THE FRONT COWL AND DISCARD.	LEN HEAD BOLIS	ß	4	00439-G6	BOLT, 5/16-18 X 1 3/4" LG	
2. AT THE TOP HOLE, INSTALL THE FRONT STRUT (ITEM	EM 7) BETWEEN	9	4	11098-G6	NUT, LOCK, 5/16-18	
	TH BOLT (ITEM 8)	۲ (-	75045-G01	STRUT, FRONT	
(ITEM 10) AND LOCK WASHER (ITEM 9) FLACING SPACER (ITEM 10) AND WASHER (ITEM 11) BETWEEN THE STRUT AND THE COWL. DO NOT TIGHTEN	O NOT TIGHTEN	ω σ	4 -	71056-G03	BOLT, 5/16-18 X 2 1/8" LG	
		۰ 10 م	4 0	00905-98 75048-G01	WASHER, LUCK, 5/16 SPACER	
3. AT THE LOWER HOLE, PROCEED AS ABOVE, SUBSTITUTING 1 W (ITEM 11) FOR SPACER. (ITEM 10). <i>DO NOT TIGHTEN HARDWARE</i>	ITING 1 WASHER, RDWARE.	: =	u o	00570-G2	WASHER, 5/16"	
C. SUN TOP (REFER TO DETAIL C & DETAIL D)		42	N	00753-G6	BOLT, STAINLESS STEEL, 1/4-20 X2 1/4"	20 X2 1/4"
1. PLACE SUN TOP (ITEM 1) ONTO STRUTS.		5 4 7 3	4	75051-G01	SPACER. PLASTIC	
	ONT AND ITEM 12	15	ω	00559-G7	WASHER, 1/4"	
(ITEM 14) BETWEEN THE STRUT AND UNDERSIDE OF SUN TOP, FLASTIC SFACEN,	UN TOP. SECURE	16	4	00891-G2	NUT, LOCK, 1/4-20	
		17	2	00753-G5	BOLT, STAINLESS STEEL, 1/4-20 X 2" LG	0 X 2" LG
		18	2	19853-G1	CAP, TUBE, 1"	
THE SYMBOL CREFERS TO A NOTE CORRESPONDING TO	TITLE SUN TOP INSTALLATION - TRUCK	ISTALL	ATION	- TRUCK		REV A
		DRN BY ORIG DATE	J. BRAND 10/16/95	REV BY J. REV DATE 02	J. Brand DRAWING D207796 A NO. 75351 P	PG. 2 OF 3
	E-Z-GO DIVISION OF TEXTR	RON, INC., I	P.O. BOX (388, AUGUSTA,G	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855	



.

 NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST 74041-G02 READ ALL INSTRUCTIONS BEFORE PROCEEDING. NOTE: USE A JACK OR PERSON TO ASSIST IN ELEVATING NOTE: USE A JACK OR PERSON TO ASSIST IN ELEVATING THE BUMPER DURING INSTALLATION. 1. USING A 7/32" ALLEN WRENCH, REMOVE THE FOUR ALLEN HEAD BOLTS FROM THE FRONT COWLAND DISCARD. 2. TAP TUBE CAP (ITEM 3) INTO SPACER TUBE (ITEM 2) USING A PLASTIC-FACED HAMMER. 3. AT THE TOP HOLE OF THE BUMPER, INSERT THE BOLT (ITEM 7) AND WASHER (ITEM 6) THROUGH THE BUMPER (ITEM 1), SPACER TUBE WITH CAP (ITEM 2), PLASTIC SPACER (ITEM 5) AND WASHER (ITEM 6) THROUGH THE BUMPER (ITEM 1), SPACER TUBE WITH CAP (ITEM 2), PLASTIC SPACER (ITEM 5), AND WASHER (ITEM 6) THROUGH THE BUMPER (ITEM 1), SPACER TUBE WITH CAP (ITEM 4), AND THREAD INTO HOLE. DO NOT TIGHTEN HARDWARE. 4. AT THE LOWER HOLE, PROCEED AS ABOVE, SUBSTITUTING 1 WASHER (ITEM 4), AND THEM A), EST ILLUSTRATION FOR INSTALLATION 	IRE FIELD KIT, REQUEST S BEFORE PROCEE ERSON TO ASSIST IN STALLATION. CH, REMOVE THE FOUR AL VID DISCARD. O SPACER TUBE (ITEM 2) U O SPACER TUBE (ITEM 1), SP H THE BUMPER, INSERT THE BC H THE BUMPER (ITEM 1), SP TIC SPACER (ITEM 5) AND V O NOT TIGHTEN HARDWAR CEED AS ABOVE, SUBSTITI M 5), SFF II LISTRATION FO	 74041-G02 DING. JELEVATING JELEVATING JEING A PLASTIC- JSING A PLASTIC- JUTING 1 WASHER JUTING 1 WASHER 	NOTE: DISCAI WITH 5	NOTE: DISCARD SPACER TUBE IF VEHICLE IS EQUIPPED WITH SUN TOP				
SEQUENCE. 5. TIGHTEN ALL HARDWARE TO 17-19 LBS. TORQUE.	O 17-19 LBS. TORQUE.				0 0			/ / /
ITEM 3 TUBE CAP	ITEM 4 5/16" WASHER OTV 6	ITEM 5 PLASTIC SPACER		F		DETAILA	LA	
aly.2	Q17.0		ITEM QTY		PART NO.	DESCRIPTION		
6			- 0 0	1 7404 2 7403 2 1985	74040-G01 74037-G01 19859-G1	BUMPER SPACER TUBE TUBE CAP		
			م 4		00570-G2 75048-G01	FLAT WASHER, 5/16 SPACER		
5/16" LOCK WASHER QTY. 4	5/16-18 X 2 5/8" BOLT QTY. 4		9	· · · ·	00905-G8 71056-G02	LOCK WASHER, 5/16 BOLT, 5/16 - 18 X 2 5/8" LG	8" LG	
NOTE: ALL HARDWARE SHOWN ACTUAL SIZE	WN ACTUAL SIZE							
		TITLE BUMPER INSTALLATION - TRUCK	ISTALLAT	ION - TR	NCK		REV	- >
SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	ES AND PARTS LISTS. TATE THE ORDERING OF		DRN BY J. BI ORIG DATE 09/1	J. BRAND REV BY 09/12 /95 REV DATE	VTE VTE	A DRAWING NO. 753	55	PG. 1 OF 1
REPLACEMENT PARTS.		E-Z-GO DIVISION OF TEXTF	P.O., INC., P.O.	BOX 388, AU	GUSTA,GA.	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855		

READ ALL INSTRUCTIONS BEFORE PROCEEDING.

A. POSITION ENCLOSURE ON SUN TOP

- 1. Place folded enclosure on Sun Top.
- 2. Unfold the enclosure and reposition as necessary to allow clear rear window of enclosure to drape between the seat back and the cargo bed. The sides should hang naturally to the floorboard sill plates.
- 3. Move enclosure forward just enough to allow front edge to fit over the front edge of the Sun Top. Pull enclosure toward rear of vehicle to smooth out wrinkles.

B. APPLY VELCRO TAPE TO FRONT STRUTS

- 1. Remove the Velcro tape (hook tape) from the front edge of side curtain.
- 2. Remove the backing tape from the hook tape and, starting at the top of the strut just over the bend, apply the tape to the full length on the side of the front strut.
- 3. Repeat the procedure to the front strut on the other side.

C. SECURE FRONT OF ENCLOSURE TO FRONT STRUT

- 1. Starting at the top of enclosure front edge, attach enclosure to front strut by pressing enclosure edge to tape on side of front strut.
- 2. Repeat procedure on other side of vehicle.


D. ATTACH STRAPPED HOOKS TO LOWER EDGE OF BODY

- 1. Loosen straps with hook attached to allow enough strap length so hooks may be hooked over the lower edge of floorboard sill plate at each end, and at rear of seat.
- 2. Pull strap end to tighten enclosure.
- 3. Repeat procedure on other side of vehicle.
- 4. Adjust straps as necessary to remove wrinkles from enclosure and obtain a snug fit. .

E. OPEN SIDE

- 1. To open the side of enclosure, loosen hook straps, move zipper to the top of track, loosen front edge from strut.
- 2. Starting at the bottom, roll the side curtain up to the top and secure with straps under flap on side of top.

WEATHER EN	CLOSURE INSTA	LLATION INSTRUC	CTIONS		REV -
	DRN BY J.RICE ORIG DATE 12/15/95	REV BY REV DATE	DRAWING NO.	75368	PG. 1 OF 2
E-Z-GO DIVI		, P.O. BOX 388, AUGUSTA,G		8-7476	





E-Z-GO Division of Textron Inc. P.O. Box 388 Augusta, Georgia 30903-0388 Telephone 1-800-241-5855

> Copyrighted Material This manual may not be reproduced in whole or in part without the express permission of E-Z-GO Division of Textron Inc. Technical Communications Department